

## **SPEAKER SYSTEMS**

# S112IVN/S115IVN/S215IVN SM10IVN/SM12IVN/SM15IVN

**SUBWOOFER** 

SW118IVN/SW215IVN

**CROSSOVER NETWORK** 

**PN90** 

Owner's Manual
Mode d'emploi
Bedienungsanleitung
Manual de instrucciónes

Thank you for purchasing a YAMAHA product. To obtain maximum performance from your YAMAHA speaker system and ensure many years of trouble-free operation, we recommend that you read this Owner's Manual thoroughly before use.

### **Contents**

Precautions	2
Connecting the Speakers	4
Specifications	6
Technical Data	25

## **Precautions**

# AVOID EXCESSIVE HEAT, HUMIDITY, DUST AND VIBRATION

When choosing a location for your speakers, avoid the following:

- Direct sunlight, high temperatures (such as near heaters), or excessively low temperatures.
- · High humidity.
- Areas subject to excessive dust accumulation and vibration.
- · Non-level or unstable surfaces.

#### **HOW TO POWER UP YOUR SOUND SYSTEM**

To avoid damage to your speakers and other parts of your system, when you turn on your system, ALWAYS turn the power amp on last! This will avoid loud, damaging pops that will annoy your audience, and blow your speakers. When you power down, the amplifier should ALWAYS be turned off first to avoid the same problems.

## To protect your speakers

When choosing a power amplifier to use with your speakers, make sure that its power output matches the speakers' power capacity (refer to the Specifications on page 6). Even if the amplifier's power output is lower than the speakers' PGM (program) power capacity, the speakers may be damaged when clipping of a high input signal occurs.

The following may cause damage to speakers:

- Feedback caused when using a microphone.
- Continuous high sound pressure level produced by electronic instruments.
- Continuous high-power output distorted signals.
- Popping noises caused by turning on equipment, or by connecting or disconnecting system components while the amplifier is turned on.

# MAKE SURE THE POWER IS OFF BEFORE MAKING OR REMOVING CONNECTIONS

Always turn the power switches of system components OFF prior to connecting or disconnecting cables. Failure to do so may result in damage to speakers as well as to connected equipment.

# DISCONNECT CABLES BEFORE MOVING THE SYSTEM

To prevent short circuits or breakage of cables, always disconnect cables prior to moving system equipment.

#### MATCH CONNECTOR POLARITY

When using two or more speaker systems, be sure match the polarity (+/-) of the speaker system connectors to those at the amplifier. If the polarities do not match, the sounds produced by the speakers will interfere with each other, making it impossible to achieve a well-balanced sound field.

# KEEP THIS OWNER'S MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE

## **Poly Switch**

All full-range loudspeakers are fitted with a self-resetting poly switch that protects the high-frequency driver from damage caused by excessive power.

If a loudspeaker cabinet loses high-frequency output, immediately remove power from the unit and wait for two to three minutes. They should allow the poly switch to reset. Re-apply power and check the performance of the high-frequency driver before continuing with the power reduced to a level that does not cause the poly switch to interrupt the signal.

On the SW118IVN/SW215IVN sub woofer, the Poly Switch protects the woofer and a similar routine should be followed if its output is lost.



This product, when used in combination with amplification and/or additional loudspeakers, may be capable of producing sound levels that could cause permanent hearing loss.

DO NOT operate at high volume levels or at a level that is uncomfortable. If you experience any discomfort or ringing in the ears, or suspect an hearing loss, you should consult an audiologist.

#### **CAUTION!**

For the five models, S112IVN, S115IVN, SM10IVN, SM12IVN, and SM15IVN, use the TS-30, TS-40, TS-80, or TS-90 speaker stand by Ultimate Support System, Inc. sold separately.

When using speaker stands, observe the following precautions to prevent the speaker stands from falling over or the speaker system being dropped.

- Use the speaker stands with their legs fully opened.
- Do not place more than one speaker on the same speaker stand.
- · Tighten fastening screws securely.
- Remove the speakers from the stands before moving the stands or adjusting their height.
- Implement measures to prevent the speaker stands from falling over.
- Use the TS-30, TS-40 at no higher than 130 cm for the S112IVN, SM10IVN, SM12IVN and at no higher than 120 cm for the S115IVN and SM15IVN.
- Use the TS-80 and TS-90 at no higher than 140 cm for all speaker models.
- The top tube of the TS-30 and TS-40 speaker stands has a diameter of 1-1/2", but is tapered to 1-3/8" at the top to fit in the mounting holes on the five models named. If you should remove the top tube from a stand, be sure to insert it with the narrow end up when reassembling.

The SW118IVN, SW215IVN subwoofer has a metal socket to allow mounting of a satellite speaker. Do not use a pole longer than 56". Use a pole with an outer diameter of 1-3/8".


#### **SPEAKER HANDLES**

The handles on your speakers are for transportation. They are not designed for suspension or hanging.

# **Connecting the Speakers**

### **CONNECTION EXAMPLE 1**

The illustration below shows audio connections for a standard setup using two speaker systems.




#### **Daisy-Chaining Speakers**

Since the speaker systems in this series are equipped with two input terminals that are internally connected in parallel, it is possible "daisy-chain" speakers by connecting the output from the power amplifier to one Neutrik connector, and a second speaker system to the other.

We do not recommend connecting more than two 8 speakers in parallel. Two parallel-connected 8 speakers have a total impedance of 4, which is the minimum that should be connected to one amplifier output channel. The S112IVN, S115IVN, SM10IVN, SM12IVN, SM15IVN and SW118IVN are 8 speakers, and two of these can safely be paralleled on one output. The S215IVN and SW215IVN, however, have an impedance of 4 and should not be parallel-connected with another S215IVN / SW215IVN or any other model.

#### **Neutrik NL4FC Plug Wiring**

If you will be using the Neutrik connectors for speaker input, wire the plugs as shown below. Be sure to use proper speaker cable—NOT shielded instrument or line cable—for all speaker connections.




Neutrik NL4FC connector

Caution: Use only unshielded speaker cable with stranded conductors to connect speakers to the speaker terminals on a power amplifier. The use of audio cable not rated as sufficient for the amplifier's maximum output level can create a potential fire hazard.

### **CONNECTION EXAMPLE 2**

This example shows audio connections for a system using SW118IVN or SW215IVN Subwoofers and a PN90 Crossover Network.




- Do not connect the PN90 between the power amplifiers and the SW118IVN, SW215IVN subwoofers, as doing so will damage the equipment.
- Although the PN90 has a standard load impedance of 15 k, it can be used with loads between 7.5 and 30 k, allowing use with most power amplifiers.
- Since the LOW signal polarity is inverted at the crossover point between the LOW and HIGH signals, be sure to reverse the polarity when connecting the SW118IVN, SW215IVN input connectors to the power amplifier output connectors.
  - This polarity correction must not be made by reversing the polarity of the connections between the PN90 and the power amplifiers, as doing so will damage the equipment. Please reverse the polarity between the power amplifiers and the SW118IVNs, SW215IVNs.
- The PN90 uses unbalanced connectors. Use shielded audio cable with high-quality phone plugs to connect the PN90.


The balance between the LOW and HIGH signal levels may be adjusted using the power amplifier volume controls. A good starting point is generally achieved for typical sound sources by raising the LOW signal level about 8 dB higher than that of the HIGH signal.

# **Specifications**

	Model	SM10IVN	S112IVN/SM12IVN	S115IVN/SM15IVN	S215IVN
Enclosure Bass reflex type					
Speaker Unit	LF	10" cone	12" cone	15" cone	15" cone x 2
	HF	1" driver		2" driver	
Frequency Response		70 Hz to 20 kHz	60 Hz to 16 kHz	55 Hz to 16 kHz	42 Hz to 16 kHz
Power	NOISE*	100 W	150 W	250 W	500 W
Capacity	PGM	200 W	300 W	500 W	1000 W
	MAX	400 W	600 W	1000 W	2000 W
Nominal Impedance			8		4
Sensitivity		95 dB SPL (1W, 1m)	97 dB SPL (1W, 1m) 99 dB SPL (1W, 1m)		(1W, 1m)
Nominal	Horizontal	60°	90°		
Dispersion	Vertical		40°		
Crossover Fre	quency	1.8 kHz	2 kHz	1.7 kHz	1.5 kHz
Input Connectors Neutrik NL4MP x 2 (parallel input)		P x 2 (parallel input)			
Dimensions (W x H x D)		560 x 339 x 277 mm	S112IVN: 400 x 638 x 318 mm	S115IVN: 475 x 712 x 362 mm	500 x 1170 x 600 mm
		300 x 339 x 277 IIIII	SM12IVN: 643 x 402 x 344 mm	SM15IVN: 720 x 485 x 345 mm	300 x 1170 x 000 mm
Weight		12.2 kg	S112IVN: 19.3 kg,	S115IVN: 27.5 kg,	46 kg
			SM12IVN: 19.5 kg,	SM15IVN: 26 kg	

### S112IVN, S115IVN







SM10IVN, SM12IVN, SM	15IVN
	120°
H   O O	30°

	Model	SW118IVN	SW215IVN	
Enclosure		Bass reflex type		
Speaker Unit		18" cone	15" cone x 2	
Frequency Response		30 Hz to 2 kHz	33 Hz to 2 kHz	
Power Capacity	NOISE*	250 W	500 W	
	PGM	500 W	1000 W	
	MAX	1000 W	2000 W	
Nominal Impedance		8	4	
Sensitivity		96 dB SPL (1W, 1m)	98 dB SPL (1W, 1m)	
Recommended Crossover Frequency		90 Hz, 12 dB/octave		
Input Connectors		Neutrik NL4MP x 2 (parallel input)		
Dimensions (W x H x D)		542 x 654 x 791 mm	1115 x 520 x 600 mm	
Weight		32.4 kg	63.5 kg	


Model	PN90
Crossover Frequency	90 Hz, 12 dB/octave
	(at 15 k load)
Recommended Load Impedance	15 k
Insertion loss	3 dB
Input Connectors	1/4" phone jack x 2
Output Connectors	1/4" phone jack x 4
Dimensions (W x H x D)	227 x 38 x 76 mm
Weight	0.6 kg



### SW118IVN



### SW215IVN



Unit: mm


**≭**: EIA RS-426

Specifications subject to change without notice


# **Technical Data / Données techniques Technische Daten / Datos técnicos**

Frequency Response / Impedance Réponse en fréquence/impédance Frequenzgang/Impedanz Respuesta en frecuencia/Impedancia


#### • SM10IVN




#### • S115IVN/SM15IVN




#### • S112IVN/SM12IVN




#### • S215IVN



#### • SW118IVN




#### • SW215IVN



## **Horizontal Directivity / Directivité horizontale** Abstrahlung horizontal / Directividad horizontal

#### • SM10IVN









### • S112IVN/SM12IVN

- 500Hz —
- 1kHz -----• 2kHz —









### • S115IVN/SM15IVN

- 500Hz • 1kHz -----
- 2kHz —




- 8kHz -----
- 16kHz —




#### • S215IVN

- 500Hz —
- 1kHz -----
- 2kHz —




- 4kHz
- 8kHz -----
- 16kHz —




## **Vertical Directivity / Directivité verticale** Vertikale Richtcharkteristik / Directividad vertical

#### • SM10IVN











### • \$112IVN/\$M12IVN

- 500Hz —
- 1kHz -----• 2kHz —









### • S115IVN/SM15IVN

- 500Hz • 1kHz -----• 2kHz —




- 4kHz
- 8kHz -----
- 16kHz —




### • S215IVN

- 500Hz • 1kHz -----
- 2kHz —



- 4kHz
- 8kHz -----
- 16kHz —





Yamaha Manual Library http://www2.yamaha.co.jp/manual/english/

M.D.G., Pro Audio & Digital Musical Instrument Division, Yamaha Corporation © 2002 Yamaha Corporation CJY0333 209AP A0 Printed in Taiwan