

## Using the TIDAL service

EN


TIDAL is the world's first music service with High Fidelity sound quality, High Definition music videos and Curated Editorial by music journalists, artists and experts, making for a simply superior experience.

After registering this unit in the MusicCast CONTROLLER app, use the TIDAL service as follows.

### 1. TIDAL account sign-in

To start using the TIDAL service on this unit, sign in to your account using the MusicCast CONTROLLER app installed on your mobile device. Follow the instructions on the app screen.

#### MusicCast CONTROLLER app



A TIDAL account is required. For details, visit the TIDAL web site.

[www.tidal.com/](http://www.tidal.com/)

#### NOTE

- If you do not have a TIDAL account, please register your account on the TIDAL web site in advance.
- To use this function, the unit must be connected to the Internet. For detail on connections and network settings, refer to "Owner's Manual".

### 2. Playback of TIDAL content

Use the MusicCast CONTROLLER app installed on your mobile device to select the TIDAL content.

#### NOTE

- The playback screen is displayed on the TV connected to the unit.

### ■ About this service

- Service is limited to certain areas.
- This service may not be available for units purchased in some regions.
- Service may change or be discontinued without notice.



TIDAL and TIDAL logo are registered trademark of Aspiro AB in the European Union and other countries.