

## DIGITAL PIANO

**P-S500**

---

**Data List  
Datenliste  
Liste des données  
Lista de datos**

<b>Piano Types in the Piano Room / Klaviermodelle im Piano Room / Types de piano dans Piano Room / Tipos de pianos de Piano Room .....</b>	<b>2</b>
<b>Voice List / Voice-Liste / Liste des sonorités / Lista de voces .....</b>	<b>3</b>
<b>Drum/SFX Kit List / Drum/SFX-Kit-Liste / Liste des kits de batterie/SFX / Lista de conjuntos de percusión/efectos especiales .....</b>	<b>10</b>
<b>Style List / Liste der Styles / Liste des styles / Lista de estilos.....</b>	<b>17</b>
<b>Song List / Song-Liste / Liste des morceaux / Lista de canciones .....</b>	<b>20</b>
<b>Chord Types for Style Playback / Akkordtypen für die Style-Wiedergabe / Types d'accords pour la reproduction de style / Tipos de acordes para reproducción de estilos .....</b>	<b>24</b>
<b>Effect Type List / Liste der Effekttypen / Liste des types d'effet / Lista de tipos de efecto.....</b>	<b>25</b>
<b>Vocal Harmony Parameter List / Liste der Vokalharmonie-Parameter / Liste des paramètres liés à l'harmonie vocale / Lista de parámetros de armonía vocal.....</b>	<b>26</b>
<b>Parameter Chart / Parametertabelle / Tableau des paramètres / Gráfico de parámetros .....</b>	<b>28</b>
<b>MIDI Implementation Chart / MIDI-Implementierungstabelle / Tableau d'implémentation MIDI / Gráfico de implementación MIDI.....</b>	<b>31</b>

# Piano Types in the Piano Room / Klaviermodelle im Piano Room / Types de piano dans Piano Room / Tipos de pianos de Piano Room

Voice Name
CFX Grand
Bösendorfer
Studio Grand
Upright Piano
Honky Tonk Upright

# Voice List / Voice-Liste / Liste des sonorités / Lista de voces

## ■ From P-S500 Panel Only

No.	Category	Voice Name	Voice Number			
			MSB	LSB	Prg	
1	Piano	CFX Grand	108	0	1	
2		Bösendorfer	108	6	1	
3		Pop Grand	108	17	2	
4		Mellow Piano	108	18	1	
5		Studio Grand	108	1	3	
6		Bright Piano	108	16	2	
7		Rock Piano	108	16	3	
8		Pop Upright	104	13	2	
9		Honky Tonk	104	13	4	
10		Superstar Grand	108	25	5	
11		MIDI Grand	104	2	3	
12		Piano&Strings	108	23	1	
13		Harpichord	0	122	7	
14		Harpichord Coupler	0	123	7	
15	E.Piano	Suitcase EP	0	118	5	
16		Vintage EP	0	116	5	
17		Tremolo Stage	0	124	5	
18		Smooth Tine	0	119	6	
19		CP80 Stage	0	113	3	
20		Sparkle Stack	0	121	6	
21		Galaxy EP	0	114	5	
22		Clavi Bright	0	112	8	
23		Organ	Whiter Bars	8	32	30
24			All Bars Out	8	32	31
25	Jazz Rotary		8	32	114	
26	Organ Accomp		0	108	18	
27	60s Combo		104	32	17	
28	Pipe Organ Principal		0	123	20	
29	Pipe Organ Tutti		0	122	20	
30	Rock Organ		10	5	9	
31	Gospel Truth		10	7	9	
32	Harmonica		0	112	23	
33	Accordion	Full Accordion Register	104	2	22	
34		French Musette Acc.	0	119	22	
35		Steirische	0	117	22	
36		Cassotto	104	0	22	
37	Guitar	ConcertGuitar	8	32	1	
38		Dynamic Nylon	0	116	25	
39		Steel Guitar	8	32	2	
40		Bright Chorus	8	45	4	
41		Semi Acoustic	8	33	7	
42		Finger Chorus	8	42	4	
43		Warm Solid	8	33	4	
44		Jazz Clean	8	32	7	
45		Guitar Hero	8	32	6	
46		Finger Amp	8	43	4	
47		Mandolin	0	114	26	
48		Pedal Steel	8	36	4	
49		Banjo	104	0	106	
50	Bass	Vintage Round	8	32	18	
51		Acoustic Bass	8	32	17	
52		Fretless Bass	8	32	20	
53		Lo Bass	104	0	40	
54		Fat Sine Resonance	104	11	39	
55	Strings	Violin	0	113	41	
56		Cello	0	112	43	
57		Real Strings	8	33	50	
58		Classical Strings	8	36	49	
59		Pizzicato	0	113	46	
60	Choir	Boys Choir	8	32	52	
61		Mmh	0	117	53	
62	Brass	Trumpet	8	32	65	
63		Muted Trumpet	0	114	60	
64		Flugel Horn	0	118	57	
65		Trombone	0	117	58	
66		Horns	104	0	61	
67		Smooth Brass	8	36	57	
68		Dynamic Brass	0	127	62	

No.	Category	Voice Name	Voice Number			
			MSB	LSB	Prg	
69	Sax	Saxophone	8	32	83	
70		Alto Sax	8	32	67	
71		Soprano Sax	0	113	65	
72		Sax Section	8	36	83	
73	Woodwind	Flute	8	32	74	
74		Oboe	8	32	69	
75		Clarinet	104	0	72	
76		Bassoon	104	0	71	
77		Pan Flute	0	113	76	
78		Bagpipe	0	112	110	
79		Recorder	0	112	75	
80		Shakuhachi	0	112	78	
81		Perc.	Vibraphone	104	1	12
82			Xylophone	104	0	14
83	Glockenspiel		104	0	10	
84	Harp		104	1	47	
85	Celesta		0	112	9	
86	Drums	Real Drums	127	0	92	
87		Real Brushes	127	0	42	
88		Analog Kit	127	0	26	
89		Symphony Kit	127	0	49	
90		Pop Latin Kit	126	0	44	
91	Synth	Wire Lead	0	120	82	
92		Soft R&B	0	119	81	
93		Crying Lead	0	114	88	
94		New Heaven	104	10	89	
95		Lektro Codes	104	2	85	
96		Synth Strings	0	112	51	
97		Light Pad	104	2	52	
98		Analog Brass	0	112	64	
99		Aerosphere	104	1	95	
100			VP Soft	104	0	90

## ■ From Smart Pianist App Only

### Main Category: Piano

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Grand Piano	CFX Grand	108	0	1	VRM
	Bösendorfer	108	6	1	VRM
	Pop Grand	108	17	2	VRM
	Mellow Piano	108	18	1	VRM
	Studio Grand	108	1	3	VRM
	Bright Piano	108	16	2	VRM
	Ambient Piano	108	27	4	VRM
	Rock Piano	108	16	3	VRM
	Stage Piano	108	31	1	VRM
	Grand Piano 1octave	108	22	2	VRM
	Grand Piano 2octaves	108	23	2	VRM
	Cocktail Piano	108	28	4	VRM
	Upright Piano	Upright Piano	108	5	3
Pop Upright		104	13	2	Natural!
70s Ballad Piano		104	14	1	Natural!
Chill Out Piano		104	15	1	Natural!
Honky Tonk Upright		104	13	4	Natural!
Upright 1octave		104	14	4	Natural!
Upright 2octaves		104	15	4	Natural!
Piano Layer	Superstar Grand	108	25	5	Natural!
	Imperial Ballad	108	26	5	Natural!
	MIDI Grand	104	2	3	Natural!
	MIDI Grand Pad	104	3	3	Natural!
	Grand Pad Layer	108	32	3	Natural!
	Piano & EP	108	25	3	Natural!
	Grand Piano & Strings	108	23	1	Natural!
Electric Piano	Grand Piano & Orchestra	104	12	1	Natural!
	Suitcase EP	0	118	5	Cool!
	Vintage EP	0	116	5	Regular
	Electric Piano 1	0	119	5	Cool!
	Electric Piano 2	0	122	5	Natural!
	Stage EP	0	117	5	Regular
	Funky EP	0	123	5	Natural!
	Tremolo Suitcase EP	0	113	5	Cool!
	Tremolo Stage EP	0	124	5	Natural!
	Smooth Tine	0	119	6	Regular
CP80 Stage	0	113	3	Regular	
FM E.Piano	Magnetics	104	0	5	Regular
	Studio Ballad DX	104	9	6	Regular
	Sparkle Stack	0	121	6	Cool!
	Sweet DX	104	0	6	Cool!
	Ballad DX	0	124	6	Cool!
	DX Dynamics	0	123	6	Cool!
	Ballad Bells	104	2	6	Cool!
	Galaxy EP	0	114	5	Cool!
	DX7 EP	0	122	6	Natural!
	Dream DX	104	3	6	Cool!
	Midnight DX	104	1	6	Cool!
	Piano Sweeper	104	3	100	Regular
	Pianosphere	104	19	89	Regular
Clavi	Clavi Bright	0	112	8	Regular
	Wah Clavi	0	113	8	Regular
	Phase Clavi	0	115	8	Regular
Harpischord	Harpischord 1	0	122	7	Natural!
	Harpischord 2	8	32	113	S.Art!
	Harpischord Coupler	0	123	7	Natural!
	Grand Harpischord	0	113	7	Live!
	Harpischord & Strings	0	124	7	Natural!

### Main Category: Organ

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	Whiter Bars	8	32	30	S.Art!
	Curved Bars	0	121	17	Cool!
	All Bars Out	8	32	31	S.Art!
	Even Bars	0	111	17	Cool!
	Jazz Rotary	8	32	114	S.Art!
	Vintage Fast	0	127	17	Cool!
	Classic Bars	8	34	30	S.Art!
	Scanner Jazz	0	118	19	Cool!
	Rock Rotary	8	33	114	S.Art!
	Prog Rock Organ	8	33	30	S.Art!
	R&B Tremolo	0	111	19	Cool!
	Classic Jazz	0	117	17	Cool!
	Full Rocker	0	115	19	Cool!
	Organ Accomp 1	0	108	18	Regular
	Organ Accomp 2	0	107	18	Regular
	Organ Accomp 3	0	105	18	Regular
	Whiter Bars Slow	104	1	18	Cool!
	Whiter Bars Fast	104	0	18	Cool!
	Rotor Organ	0	117	19	Cool!
	Transistor Organ	60s Combo 1	104	32	17
60s Combo 2		104	33	17	Cool!
60s Combo 3		104	34	17	Cool!
60s Combo 4		104	35	17	Cool!
Euro Organ		0	118	17	Regular
Classical Pipe	Pipe Organ Principal	0	123	20	Natural!
	Chapel Organ	0	113	20	Regular
	Full Organ	0	112	20	Regular
	Hymn Organ	0	114	20	Regular
	Pipe Organ Tutti	0	122	20	Natural!
Theatre Pipe	Church Organ	0	115	20	Regular
	Full Theatre	0	127	19	Regular
	Tibia 8'	104	6	18	Regular
	Vox Humana 8'	104	7	18	Regular
	Theatre Kinura 8'	0	123	17	Regular
Organ Flutes	Theatre Trumpet 8'	0	124	17	Regular
	Organ Flutes	10	0	9	OrganFlutes
	USD Smile	10	1	9	OrganFlutes
	Reggae Bars	10	2	9	OrganFlutes
	Organ Pops	10	4	9	OrganFlutes
	Rock Organ	10	5	9	OrganFlutes
	Soul Percussion	10	6	9	OrganFlutes
	Gospel Truth	10	7	9	OrganFlutes
	Pad Organ	10	8	9	OrganFlutes
	Full Organ	10	9	9	OrganFlutes
	String Bars	10	0	10	OrganFlutes
	Latin Spin	10	1	10	OrganFlutes
	Shady Bars	10	2	10	OrganFlutes
	Funk Organ	10	3	10	OrganFlutes
	Ballad Organ	10	4	10	OrganFlutes
	Rich Bars	10	5	10	OrganFlutes
	Trumpet Bars	10	6	10	OrganFlutes
	Soul Bars	10	7	10	OrganFlutes
	Clari Bars	10	8	10	OrganFlutes
	Jazz Squabble	10	9	10	OrganFlutes
Euro Perc	10	0	11	OrganFlutes	
Ballad Euro	10	1	11	OrganFlutes	
Euro Reeds	10	2	11	OrganFlutes	
Even Warmth	10	3	11	OrganFlutes	
Bright Euro	10	4	11	OrganFlutes	
Full Euro	10	6	11	OrganFlutes	
Euro Pops	10	5	11	OrganFlutes	
Euro Accomp 1	10	7	11	OrganFlutes	
Euro Accomp 2	10	8	11	OrganFlutes	
Euro Accomp 3	10	9	11	OrganFlutes	
Harmonica	Harmonica	0	112	23	Sweet!
	Modern Harp	0	113	23	Regular
	Blues Harp	0	114	23	Regular

**Main Category: Organ**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Accordion	Full Accordion Register	104	2	22	Regular
	French Musette Acc.	0	119	22	Regular
	Master Accordion	0	118	22	Regular
	Steirische	0	117	22	Regular
	Jazz Accordion	0	120	22	Regular
	Cassotto	104	0	22	Regular
	Cajun	104	3	22	Regular
	Accordion Clarinet	104	1	22	Regular
	Bandoneon	0	113	24	Regular
	Tango Accordion	0	114	24	Regular
	Full Register Bass	104	5	22	Regular
	Musette Bass	0	123	22	Regular
	Master Bass	0	122	22	Regular
	Cajun Bass	104	6	22	Regular
	Accordion Bass	0	121	22	Regular
	Tango Bass	0	115	24	Regular

**Main Category: Guitar & Bass**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Nylon Acoustic	Concert Guitar	8	32	1	S.Art!
	Dynamic Nylon	0	116	25	Live!
	Flamenco Guitar	8	33	1	S.Art!
	Nylon Guitar	8	34	1	S.Art!
	Classical Guitar	0	115	25	Live!
	Slide Nylon	0	117	25	Live!
	Nylon Mute	0	119	25	Live!
	Electro Acoustic Guitar	8	35	1	S.Art!
Steel Acoustic	Steel Guitar	8	32	2	S.Art!
	Slide Steel	0	118	26	Live!
	Folk Guitar Harmonics	8	33	2	S.Art!
	Dynamic Steel	0	116	26	Live!
	Steel Guitar Strum	0	117	26	Live!
	Steel Guitar Mute	0	120	26	Live!
	12String Guitar	0	113	26	Live!
Clean Solid	Bright Chorus	8	45	4	S.Art!
	Vintage Slap	8	48	4	S.Art!
	Ballad Delay	8	46	4	S.Art!
	Vintage Pure	8	47	4	S.Art!
	Finger Bright	8	50	4	S.Art!
	Cool Wah Guitar	104	4	28	Regular
	Semi Acoustic	8	33	7	S.Art!
	Jazz Vintage	8	38	7	S.Art!
	Jazz Artist	8	39	7	S.Art!
	Smooth Jazz Guitar	8	35	7	S.Art!
	Shadowed Guitar	8	56	4	S.Art!
	Finger Chorus	8	42	4	S.Art!
	Vintage Spring	8	54	4	S.Art!
	Light Chorus	8	53	4	S.Art!
	Country Pick	8	44	4	S.Art!
	Finger Slap Slide	8	51	4	S.Art!
	Warm Solid	8	33	4	S.Art!
	Warm Electric	8	32	4	S.Art!
	Clean Solid	8	34	4	S.Art!
	Clean Electric	8	35	4	S.Art!
	Slap Solid	0	108	28	Cool!
	Funk Slap	8	49	4	S.Art!
	Single Coil Clean	8	39	4	S.Art!
	70s Solid Guitar	8	38	4	S.Art!
	Pure Vintage	8	42	6	S.Art!
	Vintage Open	0	123	28	Regular
	Chorus Solid	0	107	28	Cool!
	Clean Guitar	0	112	28	Cool!
	Jazz Clean	8	32	7	S.Art!
	Slide Clean	0	117	29	Cool!
	Muted Guitar	0	119	29	Cool!
	Slide Solid	0	110	28	Cool!

**Main Category: Guitar & Bass**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Clean Solid	Dynamic Mute	0	118	29	Cool!
	Slide Pick	104	7	28	Cool!
	Vintage Muted Guitar	104	0	29	Cool!
	Slide Finger	104	5	28	Cool!
	Vintage Muted Echo	0	115	29	Regular
	Slide Warm	104	6	28	Cool!
	Slide Jazz	104	0	27	Cool!
	Funk Guitar	0	116	29	Cool!
	Vintage Strum	0	126	28	Regular
	Tremolo Solid	0	111	28	Cool!
	Ballad Solid	0	109	28	Cool!
	Jazz Guitar	0	115	27	Cool!
	Jazz Solo Guitar	0	116	27	Cool!
	Octave Guitar	0	113	27	Regular
	Electric Guitar	0	114	29	Cool!
	60s Clean	0	117	28	Regular
	Distortion Solid	Rock Hero	8	35	6
Overdrive Wah		8	39	6	S.Art!
Vintage Rock		8	36	6	S.Art!
Vintage Blues		8	37	6	S.Art!
Stage Lead		8	38	6	S.Art!
Blues Slap Slide		8	36	5	S.Art!
Heavy Rock		8	32	5	S.Art!
Blues Bright		8	35	5	S.Art!
Classic Stack		8	41	6	S.Art!
Blues Warm		8	34	5	S.Art!
Guitar Hero		8	32	6	S.Art!
Vintage Amp		8	41	4	S.Art!
Feedbacker		8	33	5	S.Art!
Finger Amp		8	43	4	S.Art!
Rock Legend		8	34	6	S.Art!
Slide Pick Amp		104	8	28	Cool!
Crunch Guitar		8	33	6	S.Art!
Bluesy Night		8	55	4	S.Art!
Stereo Rock		104	2	31	Cool!
Half Drive		8	37	4	S.Art!
Blues Guitar	0	117	30	Cool!	
Grunge Guitar	8	40	6	S.Art!	
Metal Master	0	120	31	Regular	
World	Mandolin	0	114	26	Sweet!
	Pedal Steel	8	36	4	S.Art!
	Banjo	104	0	106	Regular
	Zither	104	1	16	Regular
	Shamisen	0	112	107	Regular
	Dulcimer	0	112	16	Regular
	Koto	0	112	108	Regular
	Hackbrett	104	2	47	Regular
	Sitar	104	0	105	Regular
	Bass	Vintage Round Bass	8	32	18
Acoustic Bass		8	32	17	S.Art!
Vintage Flatwound Bass		8	33	18	S.Art!
Soft Acoustic Bass		8	33	17	S.Art!
Vintage Mute Bass		8	32	19	S.Art!
Fretless Bass		8	32	20	S.Art!
Acoustic Bass & Cymbal		0	114	33	Regular
Fusion Bass		0	113	37	Regular
Vintage Pick Bass		104	1	35	Regular
Slap Bass		0	112	37	Regular
Electric Bass		0	114	34	Cool!
Super Fretless Bass		0	113	36	Regular
Synth Bass		Lo Bass	104	0	40
	Fat Pulse	104	2	40	Regular
	Dark Bass	104	1	40	Regular
	Wazzo Saw	104	3	81	Regular
	Moon Bass	104	0	39	Regular
	Kick Bass	104	1	39	Regular
	Tight Bass	104	3	40	Regular

**Main Category: Guitar & Bass**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Bass	Club Bass	104	2	39	Regular
	1o1 Sub	104	5	39	Regular
	Trance Bass	104	9	39	Regular
	Little Bass Synth	104	6	39	Regular
	Tekno Bass	104	7	39	Regular
	Dyno Acid Bass	104	10	39	Regular
	Perc Punch	104	8	39	Regular
	Mini Sub	104	6	40	Regular
	Square Bass	104	4	40	Regular
	Fat Sine Resonance	104	11	39	Regular
	Ballad Bass	104	7	40	Regular
	House Bass	0	116	39	Regular
	Velo Master	104	17	82	Regular
	Big Drone	0	118	39	Regular
	Sub Bass	0	114	40	Regular
	Hard Bass	0	114	39	Regular
	Resonance Bass	0	112	39	Regular
	TB Bass	0	117	40	Regular

**Main Category: Strings & Vocal**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Violin	0	113	41	Sweet!
	Solo Violin	0	112	41	Regular
	Viola	0	112	42	Regular
	Fiddle	0	112	111	Regular
	Cello	0	112	43	Regular
	Contrabass	0	112	44	Regular
String Ensemble	Real Strings	8	33	50	S.Art!
	Classical Strings	8	36	49	S.Art!
	Concert Strings	8	32	50	S.Art!
	Pizzicato	0	113	46	Live!
	Lush Strings	8	41	49	S.Art!
	Real Tremolo Strings	104	0	45	Live!
	Ballroom Strings	8	35	50	S.Art!
	Real Spiccato	104	6	49	Live!
	Studio Strings	8	32	49	S.Art!
	Movie Strings	0	123	49	Live!
	Ballad Strings	8	34	50	S.Art!
	Disco Strings 1	0	123	50	Live!
	Disco Strings 2	0	124	50	Live!
	Warm Strings	8	39	49	S.Art!
	Tremolo Strings	0	113	45	Live!
	Big Strings	8	40	49	S.Art!
	Strings	0	117	50	Live!
	Real Strings f	8	40	50	S.Art!
	Allegro	0	122	50	Live!
	Real Strings mf	8	41	50	S.Art!
	Dynamic Strings	0	124	49	Live!
	Real Strings p	8	42	50	S.Art!
	Chamber Strings	0	112	50	Regular
	Real Tremolo Sforzando	104	1	45	Live!
	Tremolo Bowing	8	34	49	S.Art!
	Spiccato	8	33	49	S.Art!
	Orchestral Layers	Tutti	0	120	50
Symphonic Unison		104	0	50	Regular
Pizzicato Glocken		0	115	46	Live!
Choir	Boys Choir Aah	8	33	52	S.Art!
	Boys Choir Ooh	8	32	52	S.Art!
	Boys Choir Aah	104	8	53	Live!
	Boys Choir Ooh	104	8	54	Live!
	Soft Choir Ooh	8	35	52	S.Art!
	Soft Choir Aah	8	36	52	S.Art!
	Boys Choir Oh-Ah (Pedal)	8	34	52	S.Art!
	Boys Choir Oh-Ah	8	49	56	S.Art!
	Gothic Vox	0	113	54	Regular
	Gospel Voices	0	116	53	Live!

**Main Category: Strings & Vocal**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Choir	Humming	0	118	53	Live!
	Hah Choir	0	114	53	Regular
	Mmh	0	117	53	Live!

**Main Category: Brass & Woodwind**

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Brass Solo	Trumpet	8	32	65	S.Art!	
	Cornet	0	119	57	Sweet!	
	Silver Trumpet	8	33	65	S.Art!	
	Muted Trumpet	0	114	60	Sweet!	
	Golden Trumpet	8	34	65	S.Art!	
	Flugel Horn	0	118	57	Sweet!	
	Big Band Trumpet	8	37	65	S.Art!	
	Trombone	0	117	58	Sweet!	
	Trumpet Fall	8	38	65	S.Art!	
	Trumpet	0	115	57	Sweet!	
	Trumpet Shake	8	35	65	S.Art!	
	Mellow Trumpet	0	120	57	Sweet!	
	Silver Trumpet	0	121	57	Sweet!	
	Muted Cornet	104	0	60	Sweet!	
	Golden Trumpet	0	122	57	Sweet!	
	Baritone Horn	0	113	59	Regular	
	Tuba	104	0	59	Regular	
	Bright Trombone	104	0	58	Sweet!	
	Baritone Hit	0	114	59	Regular	
	Alp Bass	0	113	34	Regular	
Brass Ensemble	Horns	104	0	61	Live!	
	Big Band Brass	8	37	57	S.Art!	
	Soft Horns	8	32	61	S.Art!	
	Smooth Brass	8	36	57	S.Art!	
	Dynamic Brass	0	127	62	Live!	
	Symphony Horns 1	104	1	61	Live!	
	Symphony Horns 2	104	2	61	Live!	
	Power Brass	0	121	63	Live!	
	Warm Horns	8	33	61	S.Art!	
	Accent Brass	0	109	62	Live!	
	Stopped Horns	104	3	61	Live!	
	Brass Falls f	8	34	57	S.Art!	
	Muted Horns	8	34	61	S.Art!	
	Brass Falls mf	8	35	57	S.Art!	
	Brass f	0	108	62	Live!	
	Brass mf	0	110	62	Live!	
	Soft Horns	0	117	61	Live!	
	Brass p	0	111	62	Live!	
	Soft Trombones	0	118	61	Live!	
	Brass Shake	8	32	57	S.Art!	
	Pop Brass	0	117	63	Live!	
	Accent Falls	8	38	57	S.Art!	
	Hyper Brass	0	118	63	Live!	
	Sforzando	0	105	62	Live!	
	Small Brass	0	120	61	Live!	
	Sforzando Fall	0	107	62	Live!	
	Ballroom Brass	0	113	60	Regular	
	Brass Dynamics	0	106	62	Live!	
	Octave Brass	0	116	63	Live!	
	Sax Solo	Saxophone	8	32	83	S.Art!
		Alto Sax	8	32	67	S.Art!
		Big Band Sax	8	35	83	S.Art!
Soft Alto Sax		8	34	67	S.Art!	
Rock Sax		8	33	83	S.Art!	
Growl Sax		0	111	67	Sweet!	
Soprano Sax		0	113	65	Sweet!	
Pop Tenor Sax		0	127	67	Sweet!	
Pop Alto Sax		104	0	66	Sweet!	
Ballad Tenor Sax		0	126	67	Sweet!	
Breathy Tenor Sax		0	117	67	Sweet!	

**Main Category: Brass & Woodwind**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Sax Solo	Jazz Tenor Sax	0	125	67	Sweet!
	Baritone Sax	104	0	68	Regular
Sax Ensemble	Sax Section	8	36	83	S.Art!
	Sax Section Unison	8	38	83	S.Art!
	Sax Section Fast Attack	0	116	67	Live!
	Big Band Saxes	0	110	67	Live!
	Sax Section Octave	8	37	83	S.Art!
	Ballad Section	0	119	67	Regular
	Soft Saxes	8	39	83	S.Art!
	Sax Appeal	0	123	67	Live!
	Sax Section Hard	0	122	67	Live!
	Sax Section Soft	0	121	67	Live!
Woodwind Solo	Flute	8	32	74	S.Art!
	Jazz Flute	0	114	74	Sweet!
	Oboe	8	32	69	S.Art!
	Classical Oboe	0	113	69	Sweet!
	Clarinet	104	0	72	Live!
	Jazz Clarinet	0	114	72	Sweet!
	Bassoon	104	0	71	Sweet!
	Bassoon	0	112	71	Regular
	German Clarinet	104	2	72	Regular
	Classical Flute	0	115	74	Sweet!
	Piccolo	0	112	73	Regular
	Oboe	0	112	69	Regular
	Clarinet	0	112	72	Regular
	English Horn	0	112	70	Regular
Woodwind Ens	Flutes & Oboes	104	2	74	Regular
	Orchestral Woodwind	104	1	71	Regular
	Clarinet & Flutes	104	1	72	Regular
	Alto Flutes	104	1	74	Regular
	Clarinet & Oboe	104	1	69	Regular
	Flute Ensemble	0	116	74	Regular
	Oboe & Bassoon	104	2	69	Regular
Woodwind World	Pan Flute	0	113	76	Sweet!
	Chiff Pan Flute	0	113	74	Regular
	Celtic Duo	0	120	74	Regular
	Ethnic Flute	0	112	76	Regular
	Bagpipe	0	112	110	Regular
	Ocarina	0	112	80	Regular
	Recorder	0	112	75	Regular
	Shakuhachi	0	112	78	Regular
	Whistle	0	112	79	Regular

**Main Category: Perc & Drums**

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Chromatic Perc	Vibraphone	104	1	12	Sweet!	
	Xylophone	104	0	14	Regular	
	Jazz Vibraphone	0	113	12	Regular	
	Marimba	104	0	13	Regular	
	Tremolo Vibraphone	0	124	12	Natural!	
	Vibraphone	0	122	12	Natural!	
	Vibraphone & JazzGt	8	33	12	S.Art!	
	Glockenspiel	104	0	10	Regular	
	Vibraphone & Flutes	0	114	12	Regular	
	Steel Drums	0	112	115	Regular	
	Music Box	0	112	11	Regular	
	Kalimba	0	112	109	Regular	
	Orchestral Perc	Harp	104	1	47	Regular
		Tubular Bells	0	112	15	Regular
Timpani		0	112	48	Regular	
Orchestra Hit		0	112	56	Regular	
Celesta		0	112	9	Regular	
Drum Kits	Real Drums	127	0	92	Live!Drums	
	Real Brushes	127	0	42	Live!Drums	
	Power Kit 1	127	0	88	Live!Drums	
	Power Kit 2	127	0	89	Live!Drums	

**Main Category: Perc & Drums**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Drum Kits	Acoustic Kit	127	0	90	Live!Drums
	House Kit	127	0	61	Drums
	Rock Kit	127	0	91	Live!Drums
	Drum Machine	127	0	62	Drums
	Studio Kit	127	0	87	Live!Drums
	Analog T8 Kit	127	0	59	Drums
	Analog T9 Kit	127	0	60	Drums
	Jazz Kit	127	0	33	Drums
	Break Kit	127	0	58	Drums
	Hit Kit	127	0	5	Drums
	Hip Hop Kit	127	0	57	Drums
	Room Kit	127	0	9	Drums
	Dance Kit	127	0	28	Drums
	Electro Kit	127	0	25	Drums
	Analog Kit	127	0	26	Drums
	Symphony Kit	127	0	49	Live!Drums
	Brush Kit	127	0	41	Live!Drums
World Perc Kits	Turkish Kit	126	0	68	Live!SFX
	Cuban Kit	126	0	41	Live!SFX
	Pop Latin Kit	126	0	44	Live!SFX
SFX	New SFX Kit 1	126	0	3	Live!SFX
	New SFX Kit 2	126	0	4	Live!SFX
	Helicopter	104	0	126	Live!
	Noises Kit	126	0	9	SFX
	Applause 1	104	0	127	Live!
	Applause 2	104	1	127	Live!
	Sea Shore	104	0	123	Live!
	Gun Shot	104	0	128	Live!
	SFX Kit 1	126	0	1	SFX
	SFX Kit 2	126	0	2	SFX
Magic Bell	8	32	121	S.Art!	

**Main Category: Synth**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Lead	Sub Lead	104	0	81	Regular
	Wire Lead	0	120	82	Regular
	Soft Saw	104	16	82	Regular
	Soft R&B	0	119	81	Regular
	Fusion Lead	104	15	82	Regular
	Early Lead	0	118	82	Regular
	Oxygen	0	122	82	Regular
	Soft Square	104	5	81	Regular
	Matrix	0	123	82	Regular
	Detuned Vintage	104	1	85	Regular
	PWM Lead	104	1	82	Regular
	Hipa Lead	0	118	85	Regular
	Brassy Lead	104	5	63	Regular
	Punchy Hook	0	127	82	Regular
	Punch Lead	104	7	82	Regular
	Crying Lead	0	114	88	Regular
	Flange Filter	104	2	82	Regular
	Hip Lead	0	113	81	Regular
	Mouth Lead	104	0	82	Regular
	Hop Lead	0	117	81	Regular
	Tech Lead	0	117	85	Regular
	Analogon	0	115	82	Regular
	Tekkline	0	116	85	Regular
	Skyline	0	115	85	Regular
	Soft Mini	0	124	81	Regular
	Bleep Lead	104	0	85	Regular
	Fire Wire	0	116	82	Regular
Orbit Sine	0	126	81	Regular	
Synth Perc	New Heaven	104	10	89	Regular
	Heaven Pad	104	3	92	Regular
	Fantasy Bells	104	11	89	Regular
	Breath Bells	104	15	89	Regular

**Main Category: Synth**

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Perc	Itopia Bells	104	13	89	Regular	
	Next Generation	104	9	52	Regular	
	Sinesphere	104	18	89	Regular	
	Organ Bells	104	12	89	Regular	
	Spectrum Theme	104	14	89	Regular	
	Sky Bells	104	16	89	Regular	
	Flying Harmonics	104	1	100	Regular	
	Nylon Heaven	104	2	100	Regular	
	Airy Harp	104	17	89	Regular	
	Nylon Pad	104	0	100	Regular	
	Simple Comp	104	12	82	Regular	
	Bellsphere	104	5	89	Regular	
	Ballad Comp	104	6	89	Regular	
	Perc Pad	104	0	102	Regular	
	Heaven Bell	104	0	101	Regular	
	Mediterrain	0	114	100	Regular	
	Bright Pad Bell	104	7	89	Regular	
	Lektro Codes	104	2	85	Regular	
	Wild PWM	104	4	81	Regular	
	Resonant Clavi	104	2	91	Regular	
	Resonance Comp	104	4	63	Regular	
	Perc Sequence FM 1	104	7	88	Regular	
	Perc Sequence FM 2	104	8	88	Regular	
	Digital Sequenced	104	2	88	Regular	
	Synth Sticks	104	0	107	Regular	
	Analog Sequenced	104	3	88	Regular	
	Saz Feeze	104	0	98	Regular	
	Perc Sequence FS	104	6	88	Regular	
	Eastern Air	104	1	98	Regular	
	Xtune	104	1	88	Regular	
	Nomad	104	1	105	Regular	
	Perc Sequence Saw	104	11	82	Regular	
	Stack Bell	104	8	89	Regular	
	Attack	104	4	82	Regular	
	Nice Bell	104	9	89	Regular	
	PWM Percussion	104	6	82	Regular	
	Synth Strings	Synth Strings 1	0	112	51	Regular
		Synth Strings 2	0	113	51	Regular
		Butter Strings	104	2	51	Regular
		Bright Saw Pad	0	113	91	Regular
		Light Pad	104	2	52	Regular
		Ober Strings	0	113	52	Regular
Hipa Strings		0	114	96	Regular	
80s Pad		104	1	52	Regular	
Octave Strings		104	4	51	Regular	
Bright Pop Pad		104	3	51	Regular	
Medium Tune Pad		104	0	51	Regular	
Doux Flange		104	3	96	Regular	
Premium Pad		104	0	52	Regular	
Bright Pad Classic		104	3	91	Regular	
Soft Ensemble		104	1	51	Regular	
Synth Brass	Analog Brass	0	112	64	Regular	
	1984 Synth	104	20	82	Regular	
	Fat Synth Brass	0	116	64	Regular	
	80s Brass	0	113	63	Regular	
	Thinh Brass	104	0	63	Regular	
	Funky Analog	0	115	63	Regular	
	Brass Profit	104	1	63	Regular	
	Techno Brass	0	114	63	Regular	
	Ober Brass	0	113	64	Regular	
	Ober Horns	0	115	64	Regular	
	Slow PWM Brass	104	2	63	Regular	
	Soft Velo Brass	0	120	63	Regular	
	Fast PWM Brass	104	6	63	Regular	
	Soft Analog	0	114	64	Regular	
Synth Pad	All or Nothing	104	6	102	Regular	
	Whisper Gallery	104	0	93	Regular	

**Main Category: Synth**

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Pad	Digisweeper	104	7	102	Regular	
	Hybrid Lines	104	4	92	Regular	
	Spectrum Pad	104	5	95	Regular	
	Midnight Special	104	3	102	Regular	
	Hybrid Pad	104	22	89	Regular	
	Atmo 5th	104	6	90	Regular	
	Deep Motion	104	4	96	Regular	
	Pad Voices	104	6	96	Live!	
	Skydiver	0	112	102	Regular	
	Aerosphere	104	1	95	Regular	
	Cross Phase	104	1	102	Regular	
	New Atmosphere	104	4	90	Regular	
	Galaxy Pad	104	3	89	Regular	
	VP Soft	104	0	90	Regular	
	Night Motion	104	4	89	Regular	
	Hot Swell	104	2	96	Regular	
	Morning Dew	104	0	95	Regular	
	Dark Fat Saw	104	2	90	Regular	
	Vapor Pad	104	1	90	Regular	
	Dark Light	104	3	90	Regular	
	Space Rider	104	1	96	Regular	
	Ambient Pad	104	0	89	Regular	
	Pearls Pad	104	2	89	Regular	
	Bright Fat Saw	104	5	91	Regular	
	Breath Pad	104	0	92	Regular	
	Early Digital	104	0	94	Regular	
	Noble Man	104	1	89	Regular	
	Super Dark Pad	0	119	90	Regular	
	Analog Pad	0	120	90	Regular	
	Analog Swell	0	119	96	Regular	
	Dark Angel Pad	0	121	90	Regular	
	Big Octave Pad	0	115	91	Regular	
	Lite Pad	0	122	90	Regular	
	Golden Age	0	115	89	Regular	
	Pop Pad	0	112	91	Regular	
	Solaris	0	114	95	Regular	
	Glorious Phase	0	114	91	Regular	
	Insomnia	0	113	95	Regular	
	Ober Sweep	0	115	96	Regular	
	Neo Warm Pad	0	115	90	Regular	
	Time Travel	0	116	89	Regular	
	Cyber Pad	0	113	100	Regular	
	Bubblespace	0	113	102	Regular	
	Bright Ober	0	113	96	Regular	
	Mellow Pad	0	117	96	Regular	
	Dark Pad	0	118	96	Regular	
	Synth Dance	Ana Dayz	104	3	52	Regular
		HPF Dance	104	0	91	Regular
		Bright Pad Trance	104	4	91	Regular
		Detuned Saw Octave	104	8	82	Regular
		Chillin Chords	104	6	52	Regular
		Dancy Hook	104	9	82	Regular
		Trance (Pedal)	104	0	96	Regular
		Vinalog Saw	104	3	82	Regular
		Club Lead	104	3	63	Regular
		Talk Mod Lead	104	0	88	Regular
		Trance Perc	104	5	82	Regular
		Chorus Saw Lead	104	10	82	Regular
		Chordmaster	104	13	82	Regular
		Faat Comp	104	4	52	Regular
		Fat Saw Hook	104	7	52	Regular
		Tech Glide	104	14	82	Regular
		Trance Sequence 1	104	4	88	Regular
		Trance Sequence 2	104	5	88	Regular
		Trance Sequence 3	104	1	91	Regular
Dance Chords		104	5	52	Regular	
Dance Hook	0	112	87	Regular		



**Main Category: Synth**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Dance	Trance Lead	0	121	81	Regular
	Octave Hook	0	113	87	Regular
Synth Effects	Water Games	104	4	102	Regular
	Spectralis	104	4	95	Regular
	My Generation	104	5	102	Regular
	Metallic Rain	104	8	102	Regular
	Rainy Day	104	5	90	Regular
	Ambient Theme	104	20	89	Regular
	Warped Waves	104	2	95	Regular
	Reflecting Zone	104	21	89	Regular
	Sound Pictures	104	3	95	Regular
	The Fog	104	9	102	Regular
	Mystic Pad	104	6	95	Regular
	Randomizer	104	10	102	Regular
	Atlantis	104	11	102	Regular
	Tric-Trac	104	2	98	Regular
	Sixth Sense	104	2	102	Regular
	Perc Sequence Hipa	104	9	88	Regular
Pitch Fall	104	0	104	Regular	

**NOTE**

Some Voices have the same name but are of different types.

# Drum/SFX Kit List / Drum/SFX-Kit-Liste / Liste des kits de batterie/SFX / Lista de conjuntos de percusión/efectos especiales

Note#	MSB-LSB-PC#		Standard Kit 1 (*3)			Standard Kit 2 (*3)			Hit Kit			Room Kit			Rock Kit (*3)		
	MIDI Note	Keyboard Note	127-0-1			127-0-2			127-0-5			127-0-9			127-0-17		
			Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#-1	Surdo Mute		3												
14	D-1	D1	Surdo Open		3												
15	D#-1	D#1	Hi O														
16	E-1	E1	Whip Slap														
17	F-1	F1	Scratch H		4												
18	F#-1	F#1	Scratch L		4												
19	G-1	G1	Finger Snap														
20	G#-1	G#1	Click Noise														
21	A-1	A1	Metronome Click														
22	A#-1	A#1	Metronome Bell														
23	B-1	B1	Seq Click L														
24	C0	C2	Seq Click H														
25	C#0	C#2	Brush Tap														
26	D0	D2	Brush Swirl	•													
27	D#0	D#2	Brush Slap														
28	E0	E2	Brush Tap Swirl	•													
29	F0	F2	Snare Roll	•													
30	F#0	F#2	Castanet														
31	G0	G2	Snare Soft			Snare Soft 2			Snare Electro						Snare Noisy		
32	G#0	G#2	Sticks														
33	A0	A2	Kick Soft						Kick Tight L								
34	A#0	A#2	Open Rim Shot			Open Rim Shot H Short			Snare Pitched								
35	B0	B2	Kick Tight						Kick Wet							Kick 2	
36	C1	C3	Kick			Kick Short			Kick Tight H							Kick Gate	
37	C#1	C#3	Side Stick			Side Stick Light			Stick Ambient								
38	D1	D3	Snare			Snare Short			Snare Ambient				Snare Snappy			Snare Rock	
39	D#1	D#3	Hand Clap														
40	E1	E3	Snare Tight			Snare Tight H			Snare Tight 2				Snare Tight Snappy			Snare Rock Tight	
41	F1	F3	Floor Tom L						Hybrid Tom 1				Tom Room 1			Tom Rock 1	
42	F#1	F#3	Hi-Hat Closed		1				Hi-Hat Closed 2		1						
43	G1	G3	Floor Tom H						Hybrid Tom 2				Tom Room 2			Tom Rock 2	
44	G#1	G#3	Hi-Hat Pedal		1				Hi-Hat Pedal 2		1						
45	A1	A3	Low Tom						Hybrid Tom 3				Tom Room 3			Tom Rock 3	
46	A#1	A#3	Hi-Hat Open		1				Hi-Hat Open 2		1						
47	B1	B3	Mid Tom L						Hybrid Tom 4				Tom Room 4			Tom Rock 4	
48	C2	C4	Mid Tom H						Hybrid Tom 5				Tom Room 5			Tom Rock 5	
49	C#2	C#4	Crash Cymbal 1														
50	D2	D4	High Tom						Hybrid Tom 6				Tom Room 6			Tom Rock 6	
51	D#2	D#4	Ride Cymbal 1														
52	E2	E4	Chinese Cymbal														
53	F2	F4	Ride Cymbal Cup														
54	F#2	F#4	Tambourine						Tambourine Light								
55	G2	G4	Splash Cymbal														
56	G#2	G#4	Cowbell														
57	A2	A4	Crash Cymbal 2														
58	A#2	A#4	Vibraslap														
59	B2	B4	Ride Cymbal 2														
60	C3	C5	Bongo H														
61	C#3	C#5	Bongo L														
62	D3	D5	Conga H Mute														
63	D#3	D#5	Conga H Open														
64	E3	E5	Conga L														
65	F3	F5	Timbale H														
66	F#3	F#5	Timbale L														
67	G3	G5	Agogo H														
68	G#3	G#5	Agogo L														
69	A3	A5	Cabasa														
70	A#3	A#5	Maracas														
71	B3	B5	Samba Whistle H	•													
72	C4	C6	Samba Whistle L	•													
73	C#4	C#6	Guiro Short														
74	D4	D6	Guiro Long	•													
75	D#4	D#6	Claves														
76	E4	E6	Wood Block H														
77	F4	F6	Wood Block L														
78	F#4	F#6	Cuica Mute														
79	G4	G6	Cuica Open														
80	G#4	G#6	Triangle Mute		2												
81	A4	A6	Triangle Open		2												
82	A#4	A#6	Shaker														
83	B4	B6	Jingle Bells														
84	C5	C7	Bell Tree														
85	C#5	(C#7)															
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

Same as StandardKit 1

\*1 Key Off: Keys marked "•" stop sounding the instant they are released.

No Sound

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

\*3 For Song playback only. Cannot be selected from the app.

Kit Name			Electro Kit			Analog Kit			Dance Kit			Jazz Kit			Brush Kit		
MSB-LSB-PC#			127-0-25			127-0-26			127-0-28			127-0-33			127-0-41		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1							Kick Dance 1								
14	D-1	D1							Kick Dance 2								
15	D#-1	D#1															
16	E-1	E1															
17	F-1	F1							Scratch Dance 1	●							
18	F#-1	F#1							Scratch Dance 2	●							
19	G-1	G1															
20	G#-1	G#1															
21	A-1	A1							Dance Perc 1								
22	A#-1	A#1							Reverse Dance 1								
23	B-1	B1							Dance Perc 2								
24	C0	C2							Hi Q Dance 1								
25	C#0	C#2							Snare Analog 3								
26	D0	D2							Vinyl Noise	●							
27	D#0	D#2							Snare Analog 4								
28	E0	E2	Reverse Cymbal	●		Reverse Cymbal	●		Reverse Cymbal	●							
29	F0	F2							Reverse Dance 2	●							
30	F#0	F#2	Hi Q 2			Hi Q 2			Hi Q 2								
31	G0	G2	Snare Snappy Electro			Snare Noisy 4			Snare Techno			Snare Jazz H			Brush Slap 2		
32	G#0	G#2							Snare Dance 1								
33	A0	A2	Kick 3			Kick 3			Kick Techno Q								
34	A#0	A#2							Rim Gate								
35	B0	B2	Kick Gate			Kick Analog Short			Kick Techno L								
36	C1	C3	Kick Gate Heavy			Kick Analog			Kick Techno			Kick Jazz			Kick Jazz		
37	C#1	C#3				Side Stick Analog			Side Stick Analog			Side Stick Light			Side Stick Light		
38	D1	D3	Snare Noisy 2			Snare Analog			Snare Clap			Snare Jazz L			Brush Slap 3		
39	D#1	D#3							Dance Clap								
40	E1	E3	Snare Noisy 3			Snare Analog 2			Snare Dry			Snare Jazz M			Brush Tap 2		
41	F1	F3	Tom Electro 1			Tom Analog 1			Tom Dance 1						Tom Brush 1		
42	F#1	F#3				Hi-Hat Closed Analog	1		Hi-Hat Closed 3		1						
43	G1	G3	Tom Electro 2			Tom Analog 2			Tom Dance 2						Tom Brush 2		
44	G#1	G#3				Hi-Hat Closed Analog 2	1		Hi-Hat Closed Analog 3		1						
45	A1	A3	Tom Electro 3			Tom Analog 3			Tom Dance 3						Tom Brush 3		
46	A#1	A#3				Hi-Hat Open Analog	1		Hi-Hat Open 3		1						
47	B1	B3	Tom Electro 4			Tom Analog 4			Tom Dance 4						Tom Brush 4		
48	C2	C4	Tom Electro 5			Tom Analog 5			Tom Dance 5						Tom Brush 5		
49	C#2	C#4				Crash Analog			Crash Analog								
50	D2	D4	Tom Electro 6			Tom Analog 6			Tom Dance 6						Tom Brush 6		
51	D#2	D#4															
52	E2	E4															
53	F2	F4															
54	F#2	F#4							Tambourine Analog								
55	G2	G4															
56	G#2	G#4				Cowbell Analog			Cowbell Dance								
57	A2	A4															
58	A#2	A#4							Vibraslap Analog								
59	B2	B4							Ride Analog								
60	C3	C5							Bongo Analog H								
61	C#3	C#5							Bongo Analog L								
62	D3	D5				Conga Analog H			Conga Analog H								
63	D#3	D#5				Conga Analog M			Conga Analog M								
64	E3	E5				Conga Analog L			Conga Analog L								
65	F3	F5															
66	F#3	F#5															
67	G3	G5															
68	G#3	G#5															
69	A3	A5															
70	A#3	A#5				Maracas 2			Maracas 2								
71	B3	B5															
72	C4	C6															
73	C#4	C#6															
74	D4	D6															
75	D#4	D#6				Claves 2			Claves 2								
76	E4	E6							Dance Perc 3								
77	F4	F6							Dance Perc 4	●							
78	F#4	F#6	Scratch H 2			Scratch H 2			Dance Breath 1								
79	G4	G6	Scratch L 2			Scratch L 2			Dance Breath 2	●							
80	G#4	G#6															
81	A4	A6															
82	A#4	A#6															
83	B4	B6															
84	C5	C7															
85	C#5	(C#7)															
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

Same as StandardKit 1

\*1 Key Off: Keys marked "●" stop sounding the instant they are released.

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

P-S500 Data List / Datenliste / Liste des données / Lista de datos

Kit Name MSB-LSB-PC#			Real Brushes 127-0-42			Symphony Kit 127-0-49			Hip Hop Kit 127-0-57			Break Kit 127-0-58			Analog T8 Kit 127-0-59		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C # -1	C # 1															
14	D -1	D 1															
15	D # -1	D # 1															
16	E -1	E 1															
17	F -1	F 1															
18	F # -1	F # 1															
19	G -1	G 1															
20	G # -1	G # 1															
21	A -1	A 1															
22	A # -1	A # 1															
23	B -1	B 1	Vintage Tip														
24	C 0	C 2	Vintage Swirl 1	•													
25	C # 0	C # 2	Vintage Slap 1														
26	D 0	D 2	Vintage Swirl 2	•													
27	D # 0	D # 2	Vintage Slap 2														
28	E 0	E 2	Vintage Tap Swirl	•													
29	F 0	F 2	Vintage Slap Swirl	•													
30	F # 0	F # 2	Vintage Swirl 3	•													
31	G 0	G 2	Vintage Slap 3														
32	G # 0	G # 2															
33	A 0	A 2	Kick Soft L			Kick Soft 2			Kick Gran Casa Open			Kick Break Heavy			Kick T8 2		
34	A # 0	A # 2	Open Rim Shot Real Brushes						Hi-Hat Reverse Drum&Bass			Snare Hip Rim 4			Snare T8 3		
35	B 0	B 2	Kick Soft H			Gran Cassa			Kick HipHop 1			Kick Break 2			T8 Kick Bass		
36	C 1	C 3	Kick Jazz Ambience			Gran Cassa Mute			Kick Analog CR			Kick Break 1			Kick T8 1		
37	C # 1	C # 3	Side Stick Real Brushes						Snare Analog Sm Rim			Snare Hip Rim 1			Snare T8 Rim		
38	D 1	D 3	Vintage Slap 4			Band Snare			Snare HipHop 1			Snare Break 3			Snare T8 2		
39	D # 1	D # 3	Clap Power						Snare Clappy			Snare Break 1			Clap T9		
40	E 1	E 3	Vintage Slap 5			Band Snare 2			Snare HipHop 2			Snare Break 2			Snare T8 1		
41	F 1	F 3	Tom Real Brushes 1									Tom Break 1			Tom T8 1		
42	F # 1	F # 3	Hi-Hat Closed Real Brushes		1				Hi-Hat Closed HipHop		2	Hi-Hat Closed Rock Soft		1	Hi-Hat Closed T8		1
43	G 1	G 3	Tom Real Brushes 2						Low Tom			Tom Break 2			Tom T8 2		
44	G # 1	G # 3	Hi-Hat Pedal Real Brushes		1				Hi-Hat Pedal HipHop		2	Hi-Hat Pedal Rock		1	Hi-Hat Pedal T8		1
45	A 1	A 3	Tom Real Brushes 3						Mid Tom L			Tom Break 3			Tom T8 3		
46	A # 1	A # 3	Hi-Hat Open Real Brushes		1				Hi-Hat Open HipHop		2	Hi-Hat Half Open Rock		1	Hi-Hat Open T8		1
47	B 1	B 3	Tom Real Brushes 4						High Tom			Tom Break 4			Tom T8 4		
48	C 2	C 4	Tom Real Brushes 5						Ride Cymbal 3			Tom Break 5			Tom T8 6		
49	C # 2	C # 4	Crash Cymbal Real Brushes 1			Hand Cymbal			Crash Cymbal 3						Crash Cymbal T8		
50	D 2	D 4	Tom Real Brushes 6						Shaker 2			Tom Break 6			Tom T8 7		
51	D # 2	D # 4	Ride Cymbal Real Brushes			Hand Cymbal Short			Scratch Bass Drum Forward			Ride Cymbal 3			Ride Cymbal T9		
52	E 2	E 4	China Cymbal Real Brushes						Scratch Bass Drum Reverse			China Cymbal 2			China Cymbal 2		
53	F 2	F 4	Ride Cup Real Brushes 1						Kick HipHop 2			Ride Cymbal Cup 2			Ride Cymbal Cup 2		
54	F # 2	F # 4							Snare HipHop Rim 2			Tambourine 1 Hit			Tambourine RX5		
55	G 2	G 4	Splash Cymbal Real Brushes						HipHop Clap 2			Splash Cymbal 2					
56	G # 2	G # 4							HipHop Snap 1			Cowbell 1			Cowbell T8		
57	A 2	A 4	Crash Cymbal Real Brushes 2			Hand Cymbal 2			Snare HipHop 3						Crash Cymbal 4		
58	A # 2	A # 4							Electric Clap 2			Cowbell RX11					
59	B 2	B 4	Ride Cup Real Brushes 2			Hand Cymbal Short 2			Kick Hip Deep						Ride Cymbal 3		
60	C 3	C 5							Kick HipHop 3						Conga T8 5		
61	C # 3	C # 5							Snare HipHop Rim 3						Conga T8 4		
62	D 3	D 5							Snare HipHop 5			Conga H Tip			Conga T8 3		
63	D # 3	D # 5							Electric Clap 1			Conga H Open Slap			Conga T8 2		
64	E 3	E 5							Handbell H			Conga H Open			Conga T8 1		
65	F 3	F 5							Kick HipHop 4			Bongo 2 H					
66	F # 3	F # 5							HipHop Clap 3			Bongo 2 L					
67	G 3	G 5							HipHop Snap 2			Conga Open			Glass H		
68	G # 3	G # 5							Snare HipHop Rim 5						Glass L		
69	A 3	A 5							HipHop Flex 1								
70	A # 3	A # 5							HipHop Flex 2			Maracas Slur			Maracas T8		
71	B 3	B 5							Shaker 2			Timbale H			Fx Gun 2		•
72	C 4	C 6							Kick HipHop 5			Timbale L			Fx Gun 1		•
73	C # 4	C # 6							Snare HipHop Rim 4			Scratch H 3		•	Analog Shaker H		•
74	D 4	D 6							Snare HipHop 6			Scratch Down		•	Analog Shaker L		•
75	D # 4	D # 6							Snare HipHop 11						Claves T8		
76	E 4	E 6							Kick HipHop 10						Hi Q 1		
77	F 4	F 6							Snare HipHop 7						Hi Q 2		
78	F # 4	F # 6							HipHop Clap 5			Scratch H 2			Scratch H 2		
79	G 4	G 6							Conga H Tip			Scratch L 2			Scratch L 2		
80	G # 4	G # 6							Conga H Heel								
81	A 4	A 6							Conga H Open								
82	A # 4	A # 6							Conga L Open 1			Kick Break 3			Analog Shaker		
83	B 4	B 6							Conga L Open 2			Kick Break 4			Sleigh Bells		
84	C 5	C 7	Wind Chime						Kick HipHop 8			Kick Break 5		•	Wind Chime		
85	C # 5	(C # 7)							HipHop Clap 6			Kick Break 6			Snare Hip 1		
86	D 5	(D 7)							Snare T8 1			Kick Break 7			Snare Hip 2		
87	D # 5	(D # 7)							Snare T8 1 H			Hi-Hat Closed Break 3			Snare Hip Gate		
88	E 5	(E 7)							HipHop Clap 7			Snare Break 4			Snare Break 1		
89	F 5	(F 7)							Tom T8 1			Snare Break 5			Kick Blip		
90	F # 5	(F # 7)							Hi-Hat Closed T8 2			Snare Break 6			Snare Fx 1		
91	G 5	(G 7)							Tom T8 2			Snare Break 7			Kick Fx Hammer		

Same as StandardKit 1

\*1 Key Off: Keys marked "•" stop sounding the instant they are released.

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

## P-S500 Data List / Datenliste / Liste des données / Lista de datos

Drum/SFX Kit List / Drum/SFX-Kit-Liste / Liste des kits de batterie/SFX / Lista de conjuntos de percusión/efectos especiales

Kit Name			Analog T9 Kit			House Kit			Drum Machine			Studio Kit			Power Kit 1		
MSB-LSB-PC#			127-0-60			127-0-61			127-0-62			127-0-87			127-0-88		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1				W Kick	●										
14	D-1	D1				Disco Fx	●										
15	D#-1	D#1				White Noise Down 1	●										
16	E-1	E1				Pink Noise Down 1	●										
17	F-1	F1				White Noise Down 2	●	4									
18	F#-1	F#1				Pink Noise Down 2	●	4									
19	G-1	G1	Snare Drum&Bass 1			White Noise Up 2	●		Snare Drum&Bass 1								
20	G#-1	G#1	Kick Break 2			White Noise Up 1	●		Kick Break 2								
21	A-1	A1	Snare Distortion			Pink Noise Up	●		Snare Distortion								
22	A#-1	A#1	Kick Tek Power			White Noise Up Release	●		Kick Tek Power								
23	B-1	B1	Kick Distortion RM			Pink Noise Up Release	●		Kick Distortion RM								
24	C0	C2	Kick T9 2			Kick T9 4			Bass Drum Hard Long								
25	C#0	C#2	Snare Analog CR			Snare T8 Rim			Bass Drum Tek Power								
26	D0	D2	Snare T9 5			Snare T8 5			Bass Drum Distortion 5								
27	D#0	D#2	Clap Analog Sm			Hand Clap			Bass Drum Distortion 3								
28	E0	E2	Snare T9 Gate 1			Snare Garg L			Bass Drum Distortion 1	●							
29	F0	F2	Snare Rock Roll	●					Bass Drum Drum&Bass 1								
30	F#0	F#2	Snare T9 3			Snare T9 3			Bass Drum Blip								
31	G0	G2	Snare T9 4			Snare T8 1			Bass Drum Analog Sm			Snare Studio 2			Snare Soft Power 1		
32	G#0	G#2	Snare T9 Gate 2			Snare T9 5			Kick T8 2								
33	A0	A2	Kick T9 4			Kick T9 1			Kick T8 3			Kick Ambience H			Kick Ambient+		
34	A#0	A#2	Snare T9 6			Snare T9 Gate			Kick T9 HD 3						Open Rim Power 1		
35	B0	B2	Kick T9 1			Kick T9 2			Kick T9 2			Kick Ambience L			Kick Power Open		
36	C1	C3	Kick T9 3			Kick T9 5			Kick T9 4			Kick Studio			Kick Power Mute		
37	C#1	C#3	Snare T9 Rim			Snare T9 Rim			Snare T9 Rim						Side Stick Power		
38	D1	D3	Snare T9 1			Snare T9 1			Snare T9 1			Snare Studio M			Snare Power 1		
39	D#1	D#3	Clap T9			Clap T9			Clap T9						Hand Clap Power		
40	E1	E3	Snare T9 2			Snare T9 2			Snare T9 4			Snare Studio L			Snare Rough		
41	F1	F3	Tom T9 1			Tom T9 1			Tom T9 1						Tom Power 1		
42	F#1	F#3	Hi-Hat Closed T9		1	Hi-Hat Closed T8		1	Hi-Hat Closed T9		1				Hi-Hat Closed Power	1	
43	G1	G3	Tom T9 2			Tom T9 2			Tom T9 2						Tom Power 2		
44	G#1	G#3	Hi-Hat Pedal T9		1	Hi-Hat Pedal T9		1	Hi-Hat Pedal T9		1				Hi-Hat Pedal Power	1	
45	A1	A3	Tom T9 3			Tom T9 3			Tom T9 3						Tom Power 3		
46	A#1	A#3	Hi-Hat Open T9		1	Hi-Hat Open T9		1	Hi-Hat Open T9		1				Hi-Hat Open Power	1	
47	B1	B3	Tom T9 4			Tom T9 4			Tom T9 4						Tom Power 4		
48	C2	C4	Tom T9 5			Tom T9 5			Tom T9 5						Tom Power 5		
49	C#2	C#4	Crash Cymbal T9			Crash Cymbal T9			Crash Cymbal T9						Crash Cymbal Acoustic 1		
50	D2	D4	Tom T9 6			Tom T9 6			Conga T8 1						Tom Power 6		
51	D#2	D#4	Ride Cymbal T9			Ride Cymbal T9			Ride Cymbal T9						Ride Cymbal Acoustic 1		
52	E2	E4	China Cymbal 2			Crash Cymbal 4			Conga T8 2						China Cymbal Acoustic		
53	F2	F4	Ride Cymbal Cup 2			Ride Cymbal Cup 2			Analog Click						Ride Cymbal Cup Acoustic		
54	F#2	F#4	Tambourine RX5			Tambourine Hit			Claves T8 1								
55	G2	G4	Splash Cymbal 2			Splash Cymbal 2			Maracas T8						Splash Cymbal Acoustic		
56	G#2	G#4	Cowbell 1			Cowbell 1			Tambourine Analog CR								
57	A2	A4	Crash Cymbal 4						Analog Shaker						Crash Cymbal Acoustic 2		
58	A#2	A#4	Cowbell T8			Cowbell T8			Cowbell T8								
59	B2	B4	Ride Cymbal 3			Ride Cymbal 3			Cowbell Analog CR						Ride Cymbal Acoustic 2		
60	C3	C5	Conga T8 5			Bongo H Open One Finger			Snare T8 1								
61	C#3	C#5	Conga T8 4			Bongo L Open Three Finger			Snare T8 2								
62	D3	D5	Conga Tip			Conga H Tip			Snare T8 3								
63	D#3	D#5	Conga Open Slap			Conga H Slap Open			Snare Analog CR								
64	E3	E5	Conga Open			Conga H Open 2			Snare Jungle 1								
65	F3	F5							Snare Drum&Bass 2								
66	F#3	F#5							Snare Hip 1								
67	G3	G5	Analog Click						Snare R&B 1								
68	G#3	G#5	Conga T8 1						Snare R&B 2								
69	A3	A5							Snare Hip 1								
70	A#3	A#5	Maracas Slur 2			Maracas Slur 2			Snare Wood								
71	B3	B5	Fx Gun 2	●		Vox Drum L			Snare Timbre								
72	C4	C6	Fx Gun 1	●		Vox Drum H			Hi-Hat Closed T8 1		5						
73	C#4	C#6	Scratch H 3	●					Hi-Hat Open T8 1		5						
74	D4	D6	Scratch Down	●					Hi-Hat Closed T8 2		6						
75	D#4	D#6	Hi Q 3						Hi-Hat Open T8 2		6						
76	E4	E6	Hi Q 1						Hi-Hat Pedal Acoustic		7						
77	F4	F6	Hi Q 2						Hi-Hat Closed Acoustic		7						
78	F#4	F#6	Scratch H 2			Cuica H			Hi-Hat Open Acoustic		7						
79	G4	G6	Scratch L 2			Cuica L			Hi-Hat Closed Lo-Fi		2						
80	G#4	G#6							Hi-Hat Open Lo-Fi		2						
81	A4	A6							Hi-Hat Closed Syn		8						
82	A#4	A#6	Analog Shaker			Analog Shaker			Hi-Hat Open Syn		8						
83	B4	B6							Analog Shaker 2								
84	C5	C7	Wind Chime			Wind Chime			Tambourine RX5 2						Wind Chime		
85	C#5	(C#7)	Snare Piccolo			Snare Break Roll			Tambourine 1 Hit								
86	D5	(D7)	Snare T8 7			Noise Burst			Electric Cowbell								
87	D#5	(D#7)	SnareRockRollDist			Vox Bell			Conga T8 3								
88	E5	(E7)	Snare Brush Mute			Snare R&B 1			ElectricTriangle								
89	F5	(F7)	Kick Blip Hard			Vox Alk			Claves T8 2								
90	F#5	(F#7)	Snare Jungle 1			Udu High			Analog Shaker 3								
91	G5	(G7)	Kick Sustain			Filter Kick			Electric Clap 1								

Same as StandardKit 1

\*1 Key Off: Keys marked \*●\* stop sounding the instant they are released.

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

## P-S500 Data List / Datenliste / Liste des données / Lista de datos

Drum/SFX Kit List / Drum/SFX-Kit-Liste / Liste des kits de batterie/SFX / Lista de conjuntos de percusión/efectos especiales

Kit Name			Power Kit 2			Acoustic Kit			Rock Kit			Real Drums		
MSB-LSB-PC#			127-0-89			127-0-90			127-0-91			127-0-92		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1												
14	D-1	D1												
15	D#-1	D#1												
16	E-1	E1												
17	F-1	F1												
18	F#-1	F#1												
19	G-1	G1												
20	G#-1	G#1												
21	A-1	A1												
22	A#-1	A#1												
23	B-1	B1												
24	C0	C2												
25	C#0	C#2												
26	D0	D2										Brush Tap Swirl	•	
27	D#0	D#2												
28	E0	E2												
29	F0	F2				Snare Roll Acoustic	•		Snare Roll Rock	•		Snare Roll Rock	•	
30	F#0	F#2												
31	G0	G2	Snare Soft Power 2			Snare Soft Acoustic			Snare Soft Rock			Snare Tight		
32	G#0	G#2												
33	A0	A2	Kick Ambient+			Kick Soft Acoustic			Kick Soft Rock			Kick Genuine		
34	A#0	A#2	Open Rim Power 2			Rim Acoustic			Rim Rock			Rim Real		
35	B0	B2	Kick Power Open			Kick Mute Acoustic			Kick Rock Heavy			Kick Real 1		
36	C1	C3	Kick Power Mute			Kick Open Acoustic			Kick Rock			Kick Real 2		
37	C#1	C#3	Side Stick Power			Stick Acoustic			Stick Rock			Stick Real		
38	D1	D3	Snare Power 2			Snare Acoustic			Snare Rock			Snare Real 1		
39	D#1	D#3	Hand Clap Power			Hand Clap Power			Hand Clap Power			Clap Power		
40	E1	E3	Snare Loose			Snare Rough Acoustic			Snare Dry Rock			Snare Real 2		
41	F1	F3	Tom Power 1			Tom Acoustic 1			Tom Rock 1			Tom Real 1		
42	F#1	F#3	Hi-Hat Closed Power+Edge		1	Hi-Hat Closed Acoustic		1	Hi-Hat Closed Rock		1	Hi-Hat Closed Real		1
43	G1	G3	Tom Power 2			Tom Acoustic 2			Tom Rock 2			Tom Real 2		
44	G#1	G#3	Hi-Hat Pedal Power		1	Hi-Hat Pedal Acoustic		1	Hi-Hat Pedal Rock		1	Hi-Hat Pedal Real		1
45	A1	A3	Tom Power 3			Tom Acoustic 3			Tom Rock 3			Tom Real 3		
46	A#1	A#3	Hi-Hat Open Power		1	Hi-Hat Open Acoustic		1	Hi-Hat Open Rock		1	Hi-Hat Open Real		1
47	B1	B3	Tom Power 4			Tom Acoustic 4			Tom Rock 4			Tom Real 4		
48	C2	C4	Tom Power 5			Tom Acoustic 5			Tom Rock 5			Tom Real 5		
49	C#2	C#4	Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Real 1		
50	D2	D4	Tom Power 6			Tom Acoustic 6			Tom Rock 6			Tom Real 6		
51	D#2	D#4	Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Real 1		
52	E2	E4	China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Real		
53	F2	F4	Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Real		
54	F#2	F#4												
55	G2	G4	Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Real		
56	G#2	G#4												
57	A2	A4	Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Real 2		
58	A#2	A#4												
59	B2	B4	Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Real 2		
60	C3	C5												
61	C#3	C#5												
62	D3	D5												
63	D#3	D#5												
64	E3	E5												
65	F3	F5												
66	F#3	F#5												
67	G3	G5												
68	G#3	G#5												
69	A3	A5												
70	A#3	A#5												
71	B3	B5												
72	C4	C6												
73	C#4	C#6												
74	D4	D6												
75	D#4	D#6												
76	E4	E6												
77	F4	F6												
78	F#4	F#6												
79	G4	G6												
80	G#4	G#6												
81	A4	A6												
82	A#4	A#6												
83	B4	B6												
84	C5	C7	Wind Chime			Wind Chime			Wind Chime			Wind Chime		
85	C#5	(C#7)												
86	D5	(D7)												
87	D#5	(D#7)												
88	E5	(E7)												
89	F5	(F7)												
90	F#5	(F#7)												
91	G5	(G7)												

Same as StandardKit 1

\*1 Key Off: Keys marked "•" stop sounding the instant they are released.

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

P-S500 Data List / Datenliste / Liste des données / Lista de datos

Kit Name			SFX Kit 1			SFX Kit 2			New SFX Kit 1			New SFX Kit 2			Noises Kit		
MSB-LSB-PC#			126-0-1			126-0-2			126-0-3			126-0-4			126-0-9		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1															
14	D-1	D1															
15	D#-1	D#1															
16	E-1	E1															
17	F-1	F1															
18	F#-1	F#1															
19	G-1	G1															
20	G#-1	G#1															
21	A-1	A1															
22	A#-1	A#1															
23	B-1	B1															
24	C0	C2															
25	C#0	C#2															
26	D0	D2															
27	D#0	D#2															
28	E0	E2															
29	F0	F2															
30	F#0	F#2															
31	G0	G2															
32	G#0	G#2															
33	A0	A2															
34	A#0	A#2															
35	B0	B2															
36	C1	C3	Cutting Noise 1	●		Phone Call	●		Cutting Noise 1	●		Phone Call 2	●		White Noise	●	
37	C#1	C#3	Cutting Noise 2	●		Door Squeak	●		Cutting Noise 2	●		Door Squeak 2	●		Pink Noise	●	
38	D1	D3				Door Slam	●					Door Slam 2	●		White Noise Down 1	●	
39	D#1	D#3	String Slap	●		Scratch Cut	●		String Slap	●		Scratch Cut	●		Pink Noise Down 1	●	
40	E1	E3				Scratch Split	●					Scratch Split	●		White Noise Down 2	●	
41	F1	F3				Wind Chime	●					Wind Chime	●		Pink Noise Down 2	●	
42	F#1	F#3				Telephone Ring	●					Telephone Ring 2	●		White Noise Up 2	●	
43	G1	G3													White Noise Up 1	●	
44	G#1	G#3													Pink Noise Up	●	
45	A1	A3													White Noise Up Release	●	
46	A#1	A#3													Pink Noise Up Release	●	
47	B1	B3													White Noise Up LFO	●	
48	C2	C4													Pink Noise Up LFO	●	
49	C#2	C#4															
50	D2	D4															
51	D#2	D#4															
52	E2	E4	Flute Key Click	●		Car Engine Ignition	●		Flute Key Click	●		Car Engine Ignition	●				
53	F2	F4				Car Tires Squeal	●					Car Tires Squeal	●				
54	F#2	F#4				Car Passing	●					Car Passing	●				
55	G2	G4				Car Crash	●					Car Crash	●				
56	G#2	G#4				Siren	●					Siren 2	●				
57	A2	A4				Train	●					Train 2	●				
58	A#2	A#4				Jet Plane	●					Jet Plane 2	●				
59	B2	B4				Starship	●					Starship	●				
60	C3	C5				Burst	●					Burst	●				
61	C#3	C#5				Roller Coaster	●					Roller Coaster	●				
62	D3	D5				Submarine	●					Submarine	●				
63	D#3	D#5															
64	E3	E5															
65	F3	F5															
66	F#3	F#5															
67	G3	G5															
68	G#3	G#5	Shower	●		Laugh	●		Shower 2	●		Laugh	●				
69	A3	A5	Thunder	●		Scream	●		Thunder 2	●		Scream 2	●				
70	A#3	A#5	Wind	●		Punch	●		Wind 2	●		Punch 2	●				
71	B3	B5	Stream	●		Heart Beat	●		Stream 2	●		Heart Beat	●				
72	C4	C6	Bubble	●		Foot Steps	●		Bubble 2	●		Foot Steps 2	●				
73	C#4	C#6	Feed	●					Feed	●							
74	D4	D6															
75	D#4	D#6															
76	E4	E6															
77	F4	F6															
78	F#4	F#6															
79	G4	G6															
80	G#4	G#6															
81	A4	A6															
82	A#4	A#6															
83	B4	B6															
84	C5	C7	Dog	●		Machine Gun	●		Dog	●		Machine Gun 2	●				
85	C#5	(C#7)	Horse	●		Laser Gun	●		Horse	●		Laser Gun	●				
86	D5	(D7)	Bird Tweet	●		Explosion	●		Bird Tweet	●		Explosion 2	●				
87	D#5	(D#7)				Firework	●					Firework	●				
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)	Ghost	●					Ghost	●							
91	G5	(G7)	Maou	●					Maou	●							

No Sound

\*1 Key Off: Keys marked "●" stop sounding the instant they are released.

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

Kit Name			Arabic Kit (*3)			Cuban Kit			Pop Latin Kit			Turkish Kit		
MSB-LSB-PC#			126-0-36			126-0-41			126-0-44			126-0-68		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1							Cajon Low			Asma Davul Left Side		
14	D-1	D1							Cajon Slap			Asma Davul Right Side		
15	D#-1	D#1							Cajon Tip			Asma Davul Side Body		
16	E-1	E1							Claves High			Asma Davul Both Sides		
17	F-1	F1							Claves Low			Koltuk Davul Flam		
18	F#-1	F#1							Hand Clap			Koltuk Davul Teke		
19	G-1	G1										Koltuk Davul Tek		
20	G#-1	G#1							Finger Snap			Koltuk Davul Dum		
21	A-1	A1							Castanet			Bendir Teke Flam		
22	A#-1	A#1							Conga H Tip			Bendir Teke Dead		
23	B-1	B1							Conga H Heel			Bendir Tek Dead		
24	C0	C2	Nakarazan Dom						Conga H Open			Bendir Teke		
25	C#0	C#2	Cabasa						Conga H Mute			Bendir Tek		
26	D0	D2	Nakarazan Edge						Conga H Slap Open			Bendir Slap		2
27	D#0	D#2	Hager Dom						Conga H Slap			Bendir Dum		2
28	E0	E2	Hager Edge						Conga H Slap Mute			Zil Right Close		3
29	F0	F2	Bongo H						Conga L Tip			Zil Right Open		3
30	F#0	F#2	Bongo L						Conga L Heel			Zil Left Close		4
31	G0	G2	Conga H Mute						Conga L Open			Zil Left Open		4
32	G#0	G#2	Conga H Open						Conga L Mute			Tef Teke Flam		5
33	A0	A2	Conga L						Conga L Slap Open			Tef Tek Mute		5
34	A#0	A#2	Zagrouda H						Conga L Slap			Tef Teke Damped		
35	B0	B2	Zagrouda L	●					Conga L Slide	●		Tef Tek Mute Medium		
36	C1	C3	Kick Soft						Bongo H Open One Finger			Tef Dum Mute		
37	C#1	C#3	Side Stick						Bongo H Open Three Finger			Tef Cymbal		9
38	D1	D3	Snare Soft						Bongo H Rim			Tef Cymbal Mute		9
39	D#1	D#3	Arabic Hand Clap						Bongo H Tip			Tef Tremolo	●	
40	E1	E3	Snare Drum						Bongo H Heel			Tef Shake 1		
41	F1	F3	Floor Tom L						Bongo H Slap			Tef Shake 2		
42	F#1	F#3	Hi-Hat Closed		1				Bongo L Open One Finger			Tef Tek Flam		
43	G1	G3	Floor Tom H						Bongo L Open Three Finger			Tef Full Open		
44	G#1	G#3	Hi-Hat Pedal		1				Bongo L Rim			Tef Teke Open Short		
45	A1	A3	Low Tom						Bongo L Tip			Tef Tek Open Short		
46	A#1	A#3	Hi-Hat Open		1				Bongo L Heel			Tef Tek Open		
47	B1	B3	Mid Tom L						Bongo L Slap			Tef Dum Open		
48	C2	C4	Mid Tom H						Timbale L			Hollo Finger Dead		
49	C#2	C#4	Crash Cymbal 1									Hollo Slap		
50	D2	D4	High Tom									Hollo Dum		
51	D#2	D#4	Ride Cymbal 1									Kasik		1
52	E2	E4	Crash Cymbal 2									Kasik Flam		1
53	F2	F4	Duhulla Dom					Paila L	Paila L			Bass Darbuka Tek Dead		
54	F#2	F#4	Tambourine					Timbale H	Timbale H			Bass Darbuka Tek Flam		
55	G2	G4	Duhulla Tak									Bass Darbuka Teke		
56	G#2	G#4	Cowbell									Bass Darbuka Teke Other Finger		
57	A2	A4	Duhulla Sak									Bass Darbuka Teke Index Finger		
58	A#2	A#4	Claves									Bass Darbuka Tek		
59	B2	B4	Doff Dom					Paila H	Paila H			Bass Darbuka Slap		
60	C3	C5	Katam Dom					Cowbell Top	Cowbell Top			Bass Darbuka Slap Medium		7
61	C#3	C#5	Katam Tak						Cowbell 1			Bass Darbuka Dum		7
62	D3	D5	Katam Sak						Cowbell 2			Darbuka Roll Close	●	6
63	D#3	D#5	Katam Tak						Cowbell 3			Darbuka Roll Open	●	6
64	E3	E5	Doff Tak					Guiro Short	Guiro Short			Darbuka Teke Damped Flam		
65	F3	F5	Tabla Dom					Guiro Long	Guiro Long	●		Darbuka Tek Dead		
66	F#3	F#5	Tabla Tak 1						Metal Guiro Short			Darbuka Tek Damped		
67	G3	G5	Tabla Tik						Metal Guiro Long	●		Darbuka Teke Open Flam		
68	G#3	G#5	Tabla Tak 2					Tambourine	Tambourine			Darbuka Teke Open		
69	A3	A5	Tabla Sak						Tambourim Open			Darbuka Teke Other Finger 1		
70	A#3	A#5	Tabla Roll Edge	●					Tambourim Mute			Darbuka Teke Index Finger 1		
71	B3	B5	Tabla Flam						Tambourim Tip			Darbuka Tek 1		
72	C4	C6	Sagat 1					Maracas	Maracas			Darbuka Teke Other Finger 2		
73	C#4	C#6	Tabel Dom					Shaker	Shaker			Darbuka Teke Index Finger 2		
74	D4	D6	Sagat 3					Cabasa	Cabasa			Darbuka Tek 2		
75	D#4	D#6	Tabel Tak						Cuica Mute			Darbuka Slap Medium		
76	E4	E6	Sagat 2						Cuica Open			Darbuka Slap		8
77	F4	F6	Rik Dom						Cowbell High 1			Darbuka Dum		8
78	F#4	F#6	Rik Tak 2						Cowbell High 2			Bongo Tek Roll	●	
79	G4	G6	Rik Finger 1						Shekere			Bongo Flam		
80	G#4	G#6	Rik Tak 1						Shekere Tone			Bongo Tek Flam		
81	A4	A6	Rik Finger 2						Triangle Mute		1	Bongo Tek		
82	A#4	A#6	Rik Brass Tremolo	●					Triangle Open		1	Bongo Slap		
83	B4	B6	Rik Sak									Bongo Flam Hi		
84	C5	C7	Rik Tik						Wind Chime			Bongo Dum		
85	C#5	(C#7)												
86	D5	(D7)												
87	D#5	(D#7)												
88	E5	(E7)												
89	F5	(F7)												
90	F#5	(F#7)												
91	G5	(G7)												

No Sound

\*1 Key Off: Keys marked "●" stop sounding the instant they are released.

\*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

\*3 For Song playback only. Cannot be selected from the app.



# Style List / Liste der Styles / Liste des styles / Lista de estilos

## ■ From P-S500 Panel Only

No.	Category	Style Name
1	Pop	Standard8Beat
2		ContempGtrPop
3		80s GuitarPop
4		Chart Piano Shuffle
5		90s GuitarPop
6		Scand Pop Shuffle
7		8Beat Modern
8		Brit PopSwing
9		Classic16Beat
10	Rock	Standard Rock
11		80s PowerRock
12	70s Pop	70s Pop Duo
13		70s GlamPiano
14	60s Pop	60s Big Hit
15		60s GuitarPop
16		60s PianoPop
17		Bubblegum Pop
18	50s Rock	Rock & Roll
19		Skiffle
20	Ballad	Easy 8Beat
21		Epic Ballad
22		Power Ballad
23		8Beat Ballad
24		16Beat Ballad
25		6-8 Modern
26		Pop Waltz
27	Worship	Worship Slow
28	Soul	Detroit Pop
29		Motor City
30		LovelyShuffle
31	Dance	Club House
32		Dream Dance
33		Electronica
34		Retro Pop
35		70s Disco
36		80s Disco
37		Disco Philly
38		Disco Chocolate
39		Chillout
40		Coudy Bay
41		6-8 Trance
42	Country	70s Chart Country
43		Country Rock
44		Country Swing
45		Country Shuffle
46		Bluegrass
47		Country 2-4
48		ModCountryBld
49		Country Waltz
50	Blues	The Blues
51		6-8 Soul
52	Jazz	Acoustic Jazz
53		CoolPianoJazz
54		ModernJazzBld
55		Big Band Fast
56		Classic Big Band
57		Orchestra Swing
58		EasyListening
59		JazzWaltzFast
60		Ragtime
61		Dixieland
62	Fusion	Jazz Pop
63		FusionShuffle
64	Movie	On Broadway
65		SecretService
66		Movie Ballad
67		Showtune
68		Animation Fantasy
69	Listening	Classic Piano Bld
70		6-8 Slow Rock
71		12-8 Ballad
72	Ballroom	Quickstep
73		English Waltz

No.	Category	Style Name
74	Ballroom	Tango
75		Samba
76		Foxtrot
77		Rumba
78		Cha Cha Cha
79	Schlager	SchlagerFever
80		Schlager Fox
81		Schlager Rock
82		Schlager 6-8
83		8Beat Adria
84		Polka Pop
85	Latin	Brazilian Bossa
86		Brazilian Samba
87		Salsa
88		MariachiWaltz
89		SheriffReggae
90		Merengue
91		Pop Flamenco
92		Pop Bossa
93		Rock Cha Cha
94	World	Jig
95		Hawaiian
96		Moonlight 6-8
97		FrenchMusette
98		BohemianWaltz
99		US March
100		6-8 March

■ From Smart Pianist App Only

Category	Sub Category	Style Name		
Pop & Rock	Pop	Standard 8Beat		
		Contemp Gtr Pop		
		West Coast Beat		
		80s American Pop		
		Live 8Beat		
		80s Guitar Pop		
		Classic 8Beat		
		80s Pop		
		Chart Piano Shuffle		
		Chart Rock Shuffle		
		80s Boy Band		
		Chart Guitar Pop		
		90s Guitar Pop		
		Easy Pop		
		Chart Pop		
		Straight 8 Pop		
		Scand Pop Shuffle		
		Uptempo 8Beat		
		Brit Pop		
		8Beat Modern		
		Brit Pop Swing		
		8Beat Guitar Pop		
		Classic 16Beat		
		8Beat		
		Rock	Standard Rock	
			80s Power Rock	
			Contemp Rock	
			80s Pop Rock	
			Funk Pop Rock	
			80s Synth Rock	
			Acoustic Rock	
			Brit Rock Pop	
			Soft Rock	
			Slow Rock	
			70s Pop&Rock	70s Piano Hit
				70s Piano Rock
				70s Pop Duo
		70s Glam Piano		
	70s Swing Piano			
	Glam Piano Rock			
	70s 8Beat			
	70s Rock			
	Vintage Guitar Pop			
	60s Pop&Rock	60s Big Hit		
		60s Rising Pop		
		60s Guitar Pop		
		60s Vintage Pop		
		60s Chart Swing		
		60s Piano Pop		
		60s Rock & Roll		
		60s Pop Rock		
		Bubblegum Pop		
		60s Vintage Rock		
		60s 8Beat		
		50s Rock&Roll	Vintage R&R	
			Oldies R&R	
	Rock & Roll 1			
	Rock & Roll 2			
	Skiffle			
	Piano R&R			
	Rock & Roll Shfl			
	Pop&Rock Ballad	Easy 8Beat 1		
		Easy 8Beat 2		
		6-8 Soul Ballad		
		6-8 Ballad Rock		
		90s Piano Ballad		
		Standard Piano Bld		
		Smooth Ballad		

Category	Sub Category	Style Name	
Pop & Rock	Pop&Rock Ballad	70s Piano Pop Bld	
		Mod 6-8 Piano Bld	
		Orch Rock Ballad	
		Pop Ballad	
		Pop Guitar Ballad	
		Epic Ballad	
		Modern Pop Ballad	
		70s Chart Ballad	
		80s Movie Ballad	
		80s Synth Piano	
		80s Smooth Ballad	
		90s Cool Ballad	
		80s Analog Ballad	
		90s Rock Ballad	
		80s EP Ballad	
		Power Ballad 1	
		Power Ballad 2	
		8Beat Ballad 1	
		8Beat Ballad 2	
		MOR 16Beat	
		Acoustic Gtr Ballad	
		Easy Acoustic Bld	
		Organ Ballad	
		Pop Piano Ballad	
		EP Ballad	
		16Beat Pop	
		Contemp Rock Bld	
		16Beat Ballad	
		Modern 16Bt Ballad	
		Contemp Pop Bld	
		Acoustic Ballad	
		6-8 Modern	
		Love Song	
		Pop Waltz	
		Slow Orch Ballad	
		Piano Ballad	
		8Beat Piano Ballad	
		Worship	Worship Slow
	Worship 6-8		
	Worship Medium		
	Worship Fast		
	Worship Power Bld		
	Soul & R&B	Soul	Funky Shuffle
			Detroit Pop
			70s Cool Shuffle
			70s Chart Soul
			Motor City
			Frankly Soul
			Live Soul Band
Soul			
Kool Shuffle			
Lovely Shuffle			
Soul Beat			
Modern R&B		Modern Hip Hop	
		R&B Soul Ballad	
		Euro Hip Hop	
		Soul R&B	
		Classic Hip Hop	
		Chart R&B	
		New R&B	
		Analog Ballad	
		Clubdance	
	Ibiza 2010		
Dance	Dance	Club House	
		Dream Dance	
		Electronica	
		Funky House	
		Dancefloor	

Category	Sub Category	Style Name		
Dance	Disco	Funk Disco		
		70s Disco 1		
		70s Disco 2		
		80s Disco		
		90s Disco		
		Disco Philly		
		70s Disco Funk		
		Saturday Night		
		Synth Pop		
		Disco Fox Rock		
		80s Synth Disco		
		Movie Disco		
		Disco Chocolate		
		Chill Out	Chillout 1	
			Chillout 2	
			Night Walk	
			Chillout Cafe	
			Play 4 Sofa	
			Ethereal Synth	
			Angel Sun	
			Trance	Celtic Trance
				6-8 Trance
				Euro Trance
	Country & Blues	Modern Country	70s Country Pop	
			70s Chart Country	
			Modern Pickin'	
			Country Strum	
			Modern Bluegrass	
			Country Hits	
			Country Brothers	
			Country 8Beat	
			Country Pop	
			Country Rock	
			Trad Country	70s Country Swing
				Country Swing
				Easy Country
				Country Shuffle
				Bluegrass
		Country Sing-along		
		Hoedown		
		Standard Swing		
		Country 2-4		
		Folk Pop		
		Country Ballad	Slow Country Pop	
			Mod Country Bld	
			Country Rock Bld	
			Country Waltz	
Blues		The Blues		
		Modern Shuffle		
		Slow Blues		
		Shuffle Blues		
		6-8 Rock		
	Blueberry Blues			
	6-8 Soul			
	Blues Rock			
	Gospel Brothers			
	Gospel Sisters			
Gospel Swing				
Standards & Jazz	Jazz Combo	Cool Jazz Club		
		Jazz Guitar Club		
		Slow Jazz Ballad		
		Instrumental Jazz		
		Swing Medium		
		Fast Jazz		
		Trad Piano Jazz		
		Acoustic Jazz		
		Cool Piano Jazz		
		French Jazz		

Category	Sub Category	Style Name	
Standards & Jazz	Jazz Combo	Modern Jazz Bld 1	
		Modern Jazz Bld 2	
		Piano Boogie	
		Bebop	
	Big Band	Big Band Jazz	
		Orch Big Band 1	
		Orch Big Band 2	
		Modern Big Band	
		Mod Big Band Shfl	
		Big Band Fast 1	
		Big Band Fast 2	
		Classic Big Band	
		Afro Cuban	
		Orchestra Swing	Easy Swing
			Orchestra Swing 1
			Orchestra Swing 2
			Easy Listening
	Cool Jazz Ballad		
	Organ Groove		
	Jazz Waltz	Cool Jazz Waltz	
		Jazz Waltz Slow	
		Jazz Waltz Medium	
		Five-Four	
		Jazz Waltz Fast	
	Dixie&Trad Jazz	Ragtime 1	
		Ragtime 2	
		Dixieland 1	
		Dixieland 2	
		Charleston	
		Saloon Piano	
		Fusion	
	Jazz Pop		
	Fusion Shuffle		
	Entertainment	Movie&Show	Movie Soundtrack
			Broadway Ballad
			On Broadway
			Movie Swing
			Tap Dance Swing
			Sci-fi March
			Secret Service
			Movie Ballad
			Wild West
			Showtune
			Animation Fantasy
			Musical
			Easy Listening
		Easy Ballad	
Guitar Serenade			
6-8 Slow Rock			
6-8 Orchestral			
12-8 Ballad			
Tijuana			
Pub Piano			
Pop Classics			
Ballroom		Viennese Waltz	
		Quickstep	
		English Waltz	
		Tango	
		Slow Waltz	
		Pasodoble	
		Samba	
		Foxtrot	
		Rumba	
		Cha Cha Cha	
		Standard Waltz	
		Jive	
		Swingfox	
		Beguine	
Twist			
9-8 Waltz			

Category	Sub Category	Style Name		
Entertainment	Organ	Euro Pop Organ		
		Organ Bossa		
		Organ Samba		
		Organ Swing		
		Organ Rumba		
		Holiday	Christmas Swing	
			Christmas Ballad	
			Christmas Waltz	
			Schlager	
		Schlager	Schlager Fever	
			Schlager Palace	
			Party Arena	
			Mallorca Party	
	Alpen Schlager			
	Disco Fox			
	German Rock			
	Schlager Fox			
	Schlager Shuffle			
	Schlager Waltz			
	Alp Ballad 1			
	Alp Ballad 2			
	Schlager Samba			
	Schlager Polka			
	Schlager Rumba			
	Schlager Rock			
	Schlager 6-8			
	Scand Bugg			
	Scand Shuffle			
	Scand Slow Rock			
	Party Polka			
	8Beat Adria			
	Polka Pop			
	Scand Country			
	Latin & World		Brazil	Brazilian Bossa
				Cool Bossa
		Bossa Slow		
		Bossa Fast		
		Slow Bar Bossa		
		Samba Fast		
		Brazilian Samba		
		Bossa Nova		
		Cuba		Rumba Bolero
				Salsa
				Guajira
				Guitar Rumba
				Cuban Son
		Mexico	Mariachi Waltz	
Bolero Lento				
Caribbean		Sheriff Reggae		
		Merengue		
		Happy Reggae		
		Cumbia		
		Bachata		
		Rumba Island		
European		Flamenco		
		Sirtaki		
		Pop Flamenco		
		Tarantella		
		Spanish Paso		
Rumba Flamenco				
Latin Pop		Latin Party Pop		
		Pop Bossa		
		Pop Latin		
		Pop Latin Ballad		
		Latin Disco		
Rock Cha Cha				
Celtic		Jig		
		Reel		
		Irish Dance		
		Irish Hymn		

Category	Sub Category	Style Name
Latin & World	World	Turkish Euro
		Hawaiian
	Classic	Romantic Ballet
		Ethereal Voices
		Green Fantasia
		Baroque Air
		Moonlight 6-8
		Orchestral March
		Orchestral Bolero
		Traditional
		Arpeggio 1
		Arpeggio 2
		Trad Waltz
	Scand Waltz	
	French Waltz	
	Ober Walzer	
	Italian Waltz	
	French Musette	
	Bohemian Waltz	
	Waltz	
	March&Polka	US March
		German March
		6-8 March
		Zither Polka
		Piano March 1
		Piano March 2
	4 Stroke	
	6-8 Piano March	

# Song List / Song-Liste / Liste des morceaux / Lista de canciones

## 50 Popular

Title	Genre	Composer	Songwriter	Lyrics
Let It Go	Pop	Kristen Anderson-Lopez & Robert Lopez	Kristen Anderson-Lopez & Robert Lopez	○
Someone Like You	Pop	Adele Adkins & Dan Wilson	Adele Adkins & Dan Wilson	○
Moves Like Jagger	Pop	Adam Levine, Benjamin Levin, Ammar Malik & Johan Schuster	Adam Levine, Benjamin Levin, Ammar Malik & Johan Schuster	○
Poker Face	Pop	Stefani Germanotta & RedOne	Stefani Germanotta & RedOne	○
Hallelujah	Pop	Leonard Cohen	Leonard Cohen	○
Clocks	Pop	Guy Berryman, Jon Buckland, Will Champion & Chris Martin	Guy Berryman, Jon Buckland, Will Champion & Chris Martin	○
My Heart Will Go On (Love Theme From 'Titanic')	Pop	James Horner	Will Jennings	○
Wonderwall	Pop	Noel Gallagher	Noel Gallagher	○
Back For Good	Pop	Gary Barlow	Gary Barlow	○
Fields Of Gold	Pop	Sting	Sting	○
It Must Have Been Love	Pop	Per Gessle	Per Gessle	○
I Will Always Love You	Pop	Dolly Parton	Dolly Parton	○
Eternal Flame	Pop	Billy Steinberg, Tom Kelly & Susanna Hoffs	Billy Steinberg, Tom Kelly & Susanna Hoffs	○
Final Countdown	Pop	Joey Tempest	Joey Tempest	○
Billie Jean	Pop	Michael Jackson	Michael Jackson	○
Every Breath You Take	Pop	Sting	Sting	○
Up Where We Belong	Pop	Buffy Sainte-Marie & Jack Nitzsche	Will Jennings	○
Just The Way You Are	Pop	Billy Joel	Billy Joel	○
Wonderful Tonight	Pop	Eric Clapton	Eric Clapton	○
Dancing Queen	Pop	Benny Andersson, Bjorn Ulvaeus & Stig Anderson	Benny Andersson, Bjorn Ulvaeus & Stig Anderson	○
Candle In The Wind	Pop	Elton John & Bernie Taupin	Elton John & Bernie Taupin	○
Hey Jude	Pop	John Lennon & Paul McCartney	John Lennon & Paul McCartney	○
Can't Take My Eyes Off Of You	Pop	Bob Crewe & Bob Gaudio	Bob Crewe & Bob Gaudio	○
The House Of The Rising Sun	Pop	Alan Price	Alan Price	○
You've Lost That Lovin' Feelin'	Pop	Barry Mann, Cynthia Weil & Phil Spector	Barry Mann, Cynthia Weil & Phil Spector	○
Unchained Melody	Pop	Alex North	Hy Zaret	○
La Bamba	Pop	Ritchie Valens	Ritchie Valens	○
Moon River	Standard	Henry Mancini	Johnny Mercer	○
What A Wonderful World	Standard	George David Weiss & Bob Thiele	George David Weiss & Bob Thiele	○
The Girl From Ipanema (Garôta De Ipanema)	Standard	Antonio Carlos Jobim	Norman Gimbel	○
Spanish Eyes	Standard	Bert Kaempfert	Charles Singleton & Eddie Snyder	○
Autumn Leaves	Standard	Joseph Kosma	Johnny Mercer	○
Let There Be Love	Standard	Lionel Rand	Ian Grant	○
All The Things You Are	Standard	Jerome Kern	Oscar Hammerstein II	○
In The Mood	Standard	Joe Garland	—	
Amazing Grace	Folk	Traditional	Traditional	○
Greensleeves	Folk	Traditional	Traditional	○
Scarborough Fair	Folk	Traditional	Traditional	○
Danny Boy	Folk	Traditional	Traditional	○
Whiskey In The Jar	Folk	Traditional	Traditional	○
All I Want For Christmas Is You	Holiday & Events	Mariah Carey & Walter Afanasieff	Mariah Carey & Walter Afanasieff	○
White Christmas	Holiday & Events	Irving Berlin	Irving Berlin	○
Joy To The World	Holiday & Events	Traditional	Traditional	○
Happy Birthday To You	Holiday & Events	Traditional	Traditional	○
Auld Lang Syne	Holiday & Events	Traditional	Traditional	○
Old MacDonald Had A Farm	Children's Music	Traditional	Traditional	○
Mary Had A Little Lamb	Children's Music	Traditional	Traditional	○
Frere Jacques	Children's Music	Traditional	Traditional	○
Aura Lee	Children's Music	Traditional	Traditional	○
Yankee Doodle	Children's Music	Traditional	Traditional	○

## 50 Classics

Song Name	Composer
Canon D dur	J. Pachelbel
Air On the G String	J. S. Bach
Jesus, Joy of Man's Desiring	J. S. Bach
Twinkle, Twinkle, Little Star	Traditional
Piano Sonate op.31-2 "Tempest" 3rd mov.	L. v. Beethoven
Ode to Joy	L. v. Beethoven
Wiegenlied op.98-2	F. P. Schubert
Grande Valse Brillante	F. F. Chopin
Polonaise op.53 "Héroïque"	F. F. Chopin
La Campanella	F. Liszt
Salut d'amour op.12	E. Elgar
From the New World	A. Dvořák
Sicilienne	G. U. Fauré
Clair de lune	C. A. Debussy
Jupiter (The Planets)	G. Holst
Menuett (Eine kleine Nachtmusik K.525)	W. A. Mozart
Menuett G dur	L. v. Beethoven
Marcia alla Turca	L. v. Beethoven
Piano Concerto No.1 op.11 2nd mov.	F. F. Chopin
The Nutcracker Medley	P. I. Tchaikovsky
Prelude (Wohltemperierte Klavier I No.1)	J. S. Bach
Menuett G dur BWV Anh.114	J. S. Bach
Piano Sonate No.15 K.545 1st mov.	W. A. Mozart
Turkish March	W. A. Mozart
Piano Sonate op.13 "Pathétique" 2nd mov.	L. v. Beethoven
Für Elise	L. v. Beethoven
Piano Sonate op.27-2 "Mondschein" 1st mov.	L. v. Beethoven
Impromptu op.90-2	F. P. Schubert
Frühlingslied op.62-6	J. L. F. Mendelssohn
Fantaisie-Impromptu	F. F. Chopin
Etude op.10-3 "Chanson de l'adieu"	F. F. Chopin
Etude op.10-12 "Revolutionary"	F. F. Chopin
Valse op.64-1 "Petit chien"	F. F. Chopin
Nocturne op.9-2	F. F. Chopin
Nocturne KK4a-16/BI 49 [Posth.]	F. F. Chopin
Träumerei	R. Schumann
Barcarolle	P. I. Tchaikovsky
La prière d'une Vierge	T. Badarzewska
Liebesträume No.3	F. Liszt
Blumenlied	G. Lange
Humoresque	A. Dvořák
Arietta	E. H. Grieg
Tango (España)	I. Albéniz
The Entertainer	S. Joplin
Maple Leaf Rag	S. Joplin
La Fille aux Cheveux de Lin	C. A. Debussy
Arabesque No.1	C. A. Debussy
Cakewalk	C. A. Debussy
Je te veux	E. Satie
Gymnopédies No.1	E. Satie

■ From Smart Pianist App Only

Lesson

Album Title	Song Title
Vorschule im Klavierspiel Op.101	Beyer 1 (3hands)
	Beyer 2 (3hands)
	Beyer 3 (4hands)
	Beyer 4 (4hands)
	Beyer 5 (4hands)
	Beyer 6 (4hands)
	Beyer 7 (4hands)
	Beyer 8 (4hands)
	Beyer 9 (4hands)
	Beyer 10 (4hands)
	Beyer 11 (4hands)
	Beyer 12
	Beyer 13
	Beyer 14
	Beyer 15
	Beyer 16
	Beyer 17
	Beyer 18
	Beyer 19
	Beyer 20
	Beyer 21
	Beyer 22
	Beyer 23
	Beyer 24
	Beyer 25
	Beyer 26
	Beyer 27
	Beyer 28
	Beyer 29
	Beyer 30
	Beyer 31
	Beyer 32 (4hands)
	Beyer 33 (4hands)
	Beyer 34 (4hands)
	Beyer 35
	Beyer 36
	Beyer 37
	Beyer 38
	Beyer 39
	Beyer 40
	Beyer 41 (4hands)
	Beyer 42 (4hands)
	Beyer 43 (4hands)
	Beyer 44 (4hands)
	Beyer 45
	Beyer 46
	Beyer 47
	Beyer 48
	Beyer 49
	Beyer 50
	Beyer 51
	Beyer 52
	Beyer 53
	Beyer 54
	Beyer 55
	Beyer 56
	Beyer 57
	Beyer 58
	Beyer 59
	Beyer 60
	Beyer 61
	Beyer 62
	Beyer 63 (4hands)
	Beyer 64 (4hands)
	Beyer 65
	Beyer 66
	Beyer 67

Album Title	Song Title	
Vorschule im Klavierspiel Op.101	Beyer 68	
	Beyer 69	
	Beyer 70	
	Beyer 71	
	Beyer 72	
	Beyer 73	
	Beyer 74	
	Beyer 75	
	Beyer 76	
	Beyer 77	
	Beyer 78	
	Beyer 79	
	Beyer 80	
	Beyer 81	
	Beyer 82	
	Beyer 83	
	Beyer 84	
	Beyer 85	
	Beyer 86 (4hands)	
	Beyer 87 (4hands)	
	Beyer 88	
	Beyer 89	
	Beyer 90	
	Beyer 91	
	Beyer 92	
	Beyer 93	
	Beyer 94	
	Beyer 95	
	Beyer 96	
	Beyer 97	
	Beyer 98	
	Beyer 99	
	Beyer 100	
	Beyer 101	
	Beyer 102	
	Beyer 103	
	Beyer 104	
	Beyer 105	
	Beyer 106	
	25 Etudes faciles et progressives Op.100	1 La candeur
		2 Arabesque
		3 Pastorale
		4 Petite réunion
		5 Innocence
		6 Progrès
		7 Courant limpide
		8 La gracieuse
		9 La chasse
		10 Tendre fleur
		11 La bergersonnette
		12 Adieu
		13 Consolation
		14 La styrienne
		15 Ballade
		16 Douce plainte
		17 Babillarde
		18 Inquiétude
		19 Ave Maria
		20 Tarentelle
	21 Harmonie des anges	
	100 Übungsstücke Op.139	Czerny100 1
		Czerny100 2
		Czerny100 3


Album Title	Song Title
100 Übungsstücke Op.139	Czerny100 4
	Czerny100 5
	Czerny100 6
	Czerny100 7
	Czerny100 8
	Czerny100 9
	Czerny100 10
	Czerny100 11
	Czerny100 12
	Czerny100 13
	Czerny100 14
	Czerny100 15
	Czerny100 16
	Czerny100 17
	Czerny100 18
	Czerny100 19
	Czerny100 20
	Czerny100 21
	Czerny100 22
	Czerny100 23
	Czerny100 24
	Czerny100 25
	Czerny100 26
	Czerny100 27
	Czerny100 28
	Czerny100 29
	Czerny100 30
	Czerny100 31
	Czerny100 32
	Czerny100 33
	Czerny100 34
	Czerny100 35
	Czerny100 36
	Czerny100 37
	Czerny100 38
	Czerny100 39
	Czerny100 40
	Czerny100 41
	Czerny100 42
	Czerny100 43
	Czerny100 44
	Czerny100 45
	Czerny100 46
	Czerny100 47
	Czerny100 48
	Czerny100 49
	Czerny100 50
	Czerny100 51
	Czerny100 52
	Czerny100 53
	Czerny100 54
	Czerny100 55
	Czerny100 56
	Czerny100 57
	Czerny100 58
	Czerny100 59
	Czerny100 60
	Czerny100 61
	Czerny100 62
	Czerny100 63
	Czerny100 64
	Czerny100 65
	Czerny100 66
	Czerny100 67
	Czerny100 68
	Czerny100 69
	Czerny100 70

Album Title	Song Title
100 Übungsstücke Op.139	Czerny100 71
	Czerny100 72
	Czerny100 73
	Czerny100 74
	Czerny100 75
	Czerny100 76
	Czerny100 77
	Czerny100 78
	Czerny100 79
	Czerny100 80
	Czerny100 81
	Czerny100 82
	Czerny100 83
	Czerny100 84
	Czerny100 85
	Czerny100 86
	Czerny100 87
	Czerny100 88
	Czerny100 89
	Czerny100 90
	Czerny100 91
	Czerny100 92
	Czerny100 93
	Czerny100 94
	Czerny100 95
	Czerny100 96
	Czerny100 97
	Czerny100 98
	Czerny100 99
	Czerny100 100
30 Etudes de mécanisme Op.849	Czerny30 1
	Czerny30 2
	Czerny30 3
	Czerny30 4
	Czerny30 5
	Czerny30 6
	Czerny30 7
	Czerny30 8
	Czerny30 9
	Czerny30 10
	Czerny30 11
	Czerny30 12
	Czerny30 13
	Czerny30 14
	Czerny30 15
	Czerny30 16
	Czerny30 17
	Czerny30 18
	Czerny30 19
	Czerny30 20
	Czerny30 21
	Czerny30 22
	Czerny30 23
	Czerny30 24
	Czerny30 25
	Czerny30 26
	Czerny30 27
	Czerny30 28
	Czerny30 29
	Czerny30 30
The Virtuoso Pianist	Hanon 1
	Hanon 2
	Hanon 3
	Hanon 4
	Hanon 5
	Hanon 6
	Hanon 7
	Hanon 8
	Hanon 9

Album Title	Song Title
The Virtuoso Pianist	Hanon 10
	Hanon 11
	Hanon 12
	Hanon 13
	Hanon 14
	Hanon 15
	Hanon 16
	Hanon 17
	Hanon 18
	Hanon 19
	Hanon 20
	Hanon 1 Var.1
	Hanon 1 Var.2
	Hanon 1 Var.3
	Hanon 1 Var.4
	Hanon 1 Var.5
	Hanon 1 Var.6
	Hanon 1 Var.7
	Hanon 1 Var.8
	Hanon 1 Var.9
	Hanon 1 Var.10
	Hanon 1 Var.11
Hanon 1 Var.12	
Hanon 1 Var.13	
Hanon 1 Var.14	
Hanon 1 Var.15	
Hanon 1 Var.16	
Hanon 1 Var.17	
Hanon 1 Var.18	
Hanon 1 Var.19	
Hanon 1 Var.20	
Hanon 1 Var.21	
Hanon 1 Var.22	

# Chord Types for Style Playback / Akkordtypen für die Style-Wiedergabe / Types d'accords pour la reproduction de style / Tipos de acordes para reproducción de estilos

This section shows how to specify the indicated chords (in the key of C) when the chord detection area is set to "Lower."



Chord Name [Abbreviation]	Normal Voicing	Display for root "C"
1+8	1+8	C1+8
1+5	1+5	C1+5
Major [M]	1+3+5	C
Sixth [6]	1+(3)+5+6	C6
Major seventh [M7]	1+3+(5)+7	CM7
Major seventh flatted fifth [M7 b 5]	1+3+ b 5+7	CM7( b 5)
Major seventh add sharp eleventh [M7( # 11)]	1+(2)+3+ # 4+5+7	CM7( # 11)
Add ninth [(add9)]	1+2+3+5	Cadd9
Major seventh ninth [M7_9]	1+2+3+(5)+7	CM7(9)
Sixth ninth [6_9]	1+2+3+(5)+6	C6(9)
Flatted fifth [( b 5)]	1+3+ b 5	C b 5
Augmented [aug]	1+3+ # 5	Caug
Seventh augmented [7aug]	1+3+ # 5+ b 7	C7aug
Major seventh augmented [M7aug]	1+(3)+ # 5+7	CM7aug
Minor [m]	1+ b 3+5	Cm
Minor sixth [m6]	1+ b 3+5+6	Cm6
Minor seventh [m7]	1+ b 3+(5)+ b 7	Cm7
Minor seventh flatted fifth [m7 b 5]	1+ b 3+ b 5+ b 7	Cm7( b 5)
Minor add ninth [m(add9)]	1+2+ b 3+5	Cm add9
Minor seventh ninth [m7(9)]	1+2+ b 3+(5)+ b 7	Cm7(9)
Minor seventh eleventh [m7(11)]	1+(2)+ b 3+4+5+( b 7)	Cm7(11)
Minor major seventh flatted fifth [mM7 b 5]	1+ b 3+ b 5+7	CmM7( b 5)
Minor major seventh [mM7]	1+ b 3+(5)+7	CmM7
Minor major seventh ninth [mM7(9)]	1+2+ b 3+(5)+7	CmM7(9)
Diminished [dim]	1+ b 3+ b 5	Cdim
Diminished seventh [dim7]	1+ b 3+ b 5+6	Cdim7
Seventh [7]	1+3+(5)+ b 7	C7
Seventh suspended fourth [7sus4]	1+4+5+ b 7	C7sus4
Seventh ninth [7(9)]	1+2+3+(5)+ b 7	C7(9)
Seventh add sharp eleventh [7( # 11)]	1+(2)+3+ # 4+5+ b 7	C7( # 11)
Seventh add thirteenth [7(13)]	1+3+(5)+6+ b 7	C7(13)
Seventh flatted fifth [7 b 5]	1+3+ b 5+ b 7	C7( b 5)
Seventh flatted ninth [7( b 9)]	1+ b 2+3+(5)+ b 7	C7( b 9)
Seventh add flatted thirteenth [7( b 13)]	1+3+5+ b 6+ b 7	C7( b 13)
Seventh sharp ninth [7( # 9)]	1+ # 2+3+(5)+ b 7	C7( # 9)
Suspended fourth [sus4]	1+4+5	Csus4
One plus two plus five [sus2]	1+2+5	Csus2
cancel	1+ b 2+2	Cancel

\* Notes in parentheses can be omitted.



# Effect Type List / Liste der Effektypen / Liste des types d'effet / Lista de tipos de efecto

## Reverb Block

Category	Type Name	Description	MSB	LSB	
Reverb	Real Large Hall	Real reverb simulating the acoustics of a large sized hall.	1	32	
	Real Medium Hall	Real reverb simulating the acoustics of a medium sized hall.	1	33	
	Real Bright Hall	Real reverb simulating the acoustics of a bright sounding hall.	1	34	
	Basic Hall	Reverb simulating the acoustics of a hall. Standard setting.	1	21	
	Light Hall	Reverb simulating the acoustics of a hall. Light setting.	1	22	
	Ballad Hall	Reverb simulating the acoustics of a hall. For ballad type music.	1	19	
	Piano Hall	Reverb simulating the acoustics of a hall. For piano sound.	1	20	
	Hall 1	Reverb simulating the acoustics of a hall.	1	0	
	Hall 2		1	16	
	Hall 3		1	17	
	Hall 4		1	18	
	Hall 5		1	1	
	Vocal Hall 1	Reverb suitable for vocals.	1	27	
	Vocal Hall 2		1	28	
	Recital Hall	Reverb simulating the acoustics of a medium sized recital hall. For piano sound.	1	24	
	Concert Hall	Reverb simulating the acoustics of a large sized hall. For piano sound.	1	4	
	Cathedral	Reverb simulating the acoustics of a cathedral. For piano sound.	1	5	
	Real Room	Real reverb simulating the acoustics of a room.	2	32	
	Real Power Room	Real reverb simulating the acoustics of a room with powerful room reflections.	2	33	
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20	
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21	
	Chamber	Reverb simulating the acoustics of a chamber. For piano sound.	2	24	
	Stage	Reverb suitable for a solo instrument.	3	16	
	Club	Reverb simulating the acoustics of a club. For piano sound.	3	24	
	Real Large Plate	Real reverb simulating a large plate reverb unit.	4	32	
	Real Medium Plate	Real reverb simulating a medium sized plate reverb unit.	4	33	
	Real Rattle Plate	Real reverb simulating a plate reverb unit with spring rattle.	4	34	
	Plate	Reverb simulating a plate reverb unit.	4	16	
	Piano Plate	Reverb simulating a plate reverb unit. For piano sound.	4	24	
	Legacy	Hall M	Reverb simulating the acoustics of a hall.	1	6
		Hall L		1	7
		Atmosphere Hall	A unique long reverb with atmosphere.	1	23
		Large Hall	Reverb simulating the acoustics of a hall.	1	2
Medium Hall			1	3	
Percussion Room		Reverb simulating the acoustics of a room. For percussion sounds.	2	22	
Room 1		Reverb simulating the acoustics of a room.	2	16	
Room 2			2	17	
Room 3			2	18	
Room 4			2	19	
Room 5			2	0	
Room 6			2	1	
Room 7			2	2	
Room S			2	5	
Room M			2	6	
Room L			2	7	
Warm Room		Reverb simulating the acoustics of a warm room.	2	3	
White Room		A unique short reverb with a bit of initial delay.	16	0	
Woody Room		Reverb simulating the acoustics of a wood-built room.	2	4	
Stage 2		Reverb suitable for a solo instrument.	3	17	
Stage 3			3	0	
Stage 4			3	1	
Plate 2		Reverb simulating a plate reverb unit.	4	17	
Plate 3			4	0	
GM Plate			4	7	
Rich Plate		Reverb simulating a rich plate reverb unit.	4	1	
Tunnel		Simulates a cylindrical space expanding to left and right.	17	0	
Canyon		A hypothetical acoustic space which extends without limit.	18	0	
Basement		A bit of initial delay followed by reverb with a unique resonance.	19	0	
---		No Effect	No effect.	0	0

# Vocal Harmony Parameter List / Liste der Vokalharmonie-Parameter / Liste des paramètres liés à l'harmonie vocale / Lista de parámetros de armonía vocal

## Vocal Harmony Type List

Type Name	Description	Vocal Harmony	Vocal Effect
StandardDuet	Standard setting for lead vocal plus 1 harmony part. Useful for many music genres.	On	Off
StandardTrio	Standard setting for lead vocal plus 2 harmony parts. Useful for many music genres.	On	Off
StandardQuartet	Standard setting for lead vocal plus 3 harmony parts. Useful for many music genres.	On	Off
StudioVocals	This setting is suitable for studio production purposes. It features appropriate EQ settings and an understated Reverb.	On	On
JazzyQuartet	Good for Bass, Tenor and Alto singers; for Jazz repertoire. You will hear additional 6th notes.	On	Off
SchlagerTrio	Good for standard Schlager repertoire with simple harmony chords.	On	On
Destiny'sPop	Good for female singers with lead vocal plus 2 harmony parts above; for female Pop and R&B repertoire.	On	On
VocalDoubler	Use this preset to overdub your singing in real time. Turn the "Harmony" on to add harmony parts with Vocal Doubler effect.	Off	On
VocoderVH	This is a standard vocoder setting. It allows control of the harmony by playing keys higher than the Split Point.	On	Off
VocoderMONO	Standard vocoder setting. It allows control of the harmony by playing keys higher than the Split Point. You can play mono (single-note) melodies.	On	Off
Rock&Roll	Good for songs from the 50's and 60's with typical delay characteristics of that time. Turn the "Harmony" on to add harmony parts with Blues or Rock chords.	Off	On
TempoCross	Tempo Cross Delay on lead vocal. Turn the "Harmony" on to add harmony parts; good for Pop songs or special show effects.	Off	On
HeavyVoice	Good for Rock and Pop with overdriven vocal. Turn the "Harmony" on to add Harm.1 with 1 octave down.	Off	On
TelephoneChoir	Typical Lo-Fi vocal ensemble; use as old fashioned ensemble sound or exciting effect in Rock, Pop and Jazz.	On	On
LikeThe80s	Good for 80's Pop with typical reverb image.	On	On
Gramophone	Typical 30's vocal ensemble; reproduces an old fashioned gramophone sound.	On	On
PokerPhaser	Good for modern Pop songs using a phaser effect for lead vocal.	On	On
DetuneVoice	Lead vocal plus two additional detuned harmony parts for exciting detuned sound.	On	Off
PerfectFourth	Quartet singing only perfect fourths; parallel movement of all parts.	On	On
SingCMajorScale	Sing notes within a C major scale and the harmony parts will create suitable chord notes based on the C major scale.	On	Off
BalladChoir	Good for Ballad backing vocals with long reverb.	On	On
ChurchChoir	Good for standard church songs and Christmas songs with long reverb; recommended for Bass, Tenor and Alto voice.	On	On
GregorianChoir	Good for rubato Gregorian-chant-type monophonic songs with large reverb; parallel movement of all parts.	On	On
GospelChoir	Good for Gospel songs with long reverb on harmony parts and minor 7th feel.	On	On
CosmicChoir	Extremely phased vocals; useful for exciting effects in Dance and Modern Music.	On	On
AlpenGirls	Good for male singer with 2 female harmony parts above lead vocal.	On	On
CountryRock	Typical Country Rock quartet; recommended range is tenor/alto.	On	On
R&BDiva	Good for female alto singer for R&B repertoire; also usable with Tenor lead vocal.	On	On
ClosedPopChicks	Good for female singers with two harmony parts below.	On	On
QueenOfPop	Good for Pop and R&B songs using Tempo Delay. Turn the "Harmony" on to add 2nd Voice.	Off	On
Bob->Mary	Male singer can sound like Female voice with long romantic reverb.	On	On
Mary->Bob	Female singer can sound like Male voice with short reverb.	On	Off
FlangingVocals	Useful for modern Pop, Rock and Dance music.	Off	On
JazzySisters	Good for Bass and Tenor Singers. Harmony parts add 3 female Jazz singers.	On	On
QuartetOnStage	Good for Rock and Pop Music. Harmony parts make up a quartet.	On	On
DelayedHarmony	Useful in several genres with a tempo-synced delay choir as background.	On	On
KidsChoir	Creates the effect of a child's voice. Use this preset type and sing with your friends...	On	Off
ChorusChoir	The chorus effect adds a rich and exciting characteristics to your voice and the harmony parts.	On	On
BohemianVocode	Tempo flanging Vocoder Type; good for Rock or Pop songs and Intros.	On	On
RobotVoice	Creates a robotic voice effect. This is the setting. Use Harm.3 for variation.	On	On
ChordalXG	Chordal type setting of previous Vocal Harmony system.	On	Off
DetuneXG	Detune type setting of previous Vocal Harmony system.	On	Off
ChromaticXG	Chromatic type setting of previous Vocal Harmony system.	On	Off
VocoderXG	Vocoder type setting of previous Vocal Harmony system.	On	Off
Thru	Bypasses the processing without any harmonies and effects.	Off	Off

## Vocal Effect Type List

Type Name	Description	MSB	LSB
Romantic Rev (Romantic Reverb)	Long reverb for vocal part. Romantic image.	1	0
80s Pop Rev (80s'Pop Reverb)	Long reverb for vocal part. 80's pop image.	1	16
Room	Reverb simulating the acoustics of a room.	2	0
Stage (Concert Stage)	Reverb simulating the concert stage.	3	0
Plate	Reverb simulating a plate reverb unit.	4	0
VocalDoubler	Immediate delay with center focused feeling.	5	16
StereoSpread	Immediate delay with spread feeling.	5	17
Delay	Produces simple delayed sounds: L, R, and C (center).	5	0
Short Delay	Produces short delayed sound with narrow image.	5	1
R&R Delay (Rock&Roll Delay)	Produces slap back echo sound. Good for Rock&Roll music.	5	18
Cross Delay	The feedback of the two delayed sounds is crossed.	8	0
Tempo Delay	Tempo-synchronized delay.	21	0
Tempo Cross (Tempo Cross Delay)	Tempo-synchronized cross delay.	22	0
Chorus	Conventional chorus program with rich, warm chorusing.	66	0
EQ Hi-Fi	Equalizer effect that boosts both high and low frequencies.	76	16
EQ Tel	Equalizer effect that cuts both high and low frequencies.	76	0
Gramophone	Produces Lo-Fi sound with gramophone image.	94	0
Robot	Produces Lo-Fi sound with robotic image.	94	16
Overdriven	Produces overdriven sound. Good for rock and dance music.	98	0
Scream&Shout	Produces heavy distorted sound.	98	16
TempoFlanger	Tempo-synchronized flanger.	107	0
TempoPhaser	Tempo-synchronized phaser.	108	0
TempoAutoPan	Tempo-synchronized auto pan.	121	0
No Effect	No effect.	0	0

# Parameter Chart / Parametertabelle / Tableau des paramètres / Gráfico de parámetros

Screen		Parameter	Backup *1	Backup/Restore File *2	Registration Memory		Comment		
					Regist	Group			
Piano Room	Main	Piano Voice	x	x	○	Voice			
		Reverb Type	x	x	○	Common			
		Lid Position	○*	○*	○	Voice	*Saved for each Piano Voice.		
	Piano Room Setting	Lid Position	Lid Position	○*	○*	○	Voice	*Saved for each Piano Voice.	
		Brightness	Brightness	○*	○*	○	Voice	*Saved for each Piano Voice.	
		Touch Curve	Touch Curve	○	○	x			
			Fixed Velocity	○	○	x			
		Environment	Reverb Type	x	x	○	Common		
			Reverb Depth	○*	○*	○	Voice	*Saved for each Piano Voice.	
		Master Tune	Master Tune	○	○	x			
		VRM	VRM On/Off	○*	○*	○	Voice	*Saved for each Piano Voice.	
		Damper Resonance	Damper Resonance	○*	○*	○	Voice	*Saved for each Piano Voice.	
		String Resonance	String Resonance	○*	○*	○	Voice	*Saved for each Piano Voice.	
		Key Off Sampling	Key Off Sampling	○*	○*	○	Voice	*Saved for each Piano Voice.	
Half Pedal Point	Half Pedal Point	○	○	x					
Each Key Setting	Tune	○*	○*	x		*Saved for each Piano Voice.			
	Volume	○*	○*	x		*Saved for each Piano Voice.			
Voice	Main	Main Voice	x	x	○	Voice			
		Layer On/Off	x	x	○	Voice			
		Layer Voice	x	x	○	Voice			
		Left On/Off	x	x	○	Voice			
		Left Voice	x	x	○	Voice			
		Split Point	○	○	○	Voice, Style			
	Voice Select	Favorites	○	○	x				
	Voice Setting	Octave	Octave	x	x	○	Voice		
			Part On/Off	x	x	○	Voice		
		Mixer	Pan	x	x	○	Voice		
			Reverb Type	x	x	○	Common		
			Reverb Depth	x	x	○	Voice		
			Volume	x	x	○	Voice		
			Style	Main	Style	x	x	○	Style
Syncho Start On/Off					x	x	○	Style	
Volume	x	x			○	Style			
Tempo	x	x			○	Style			
Part On/Off	x	x			○	Style			
Section	x	x			○	Style			
Style Select	Favorites	○	○	x					
Style Setting	Fingering	Chord Detection Area	○	○	○	Style			
		Split Point	○	○	○	Voice, Style			
	Style	Intro On/Off	○	○	x				
		Ending On/Off	○	○	x				
		Dynamics Control	x	x	○	Style			
		Auto Section Change On/Off	x	x	○	Style			
		Auto Section Change Timing	x	x	○	Style			
		Auto Section Change Sensitivity	x	x	○	Style			
	Tempo	○	○	x					
	Mixer	Part On/Off	x	x	○	Style			
		Pan	x	x	○	Style			
		Reverb Type	x	x	○	Common			
Reverb Depth		x	x	○	Style				
Volume		x	x	○	Style				
Song	Main	Song	x	x	○	Song			
		AB Repeat	x	x	○	Song			
		Guide On/Off	x	x	○	Song			
		MIDI Song Volume	x	x	○	Song			
		Audio Song Volume	x	x	○*	Song	*Available only when connected to a Wi-Fi network.		
		MIDI Song Tempo	x	x	○	Song			
		Audio Song Tempo	x	x	○	Song			
		MIDI Song Transpose	x	x	○	Song			
		Audio Song Transpose	x	x	○	Song			

Screen		Parameter	Backup *1	Backup/Restore File *2	Registration Memory		Comment	
					Regist	Group		
Song	Main	Part On/Off	x	x	○	Song	Available only when selecting a MIDI Song.	
		Chord Chart	○*	○*	x		*Saved for each Audio Song, but not MIDI Songs.	
	Song Select	Favorites	○	○*	x		*Songs in "Music Library" category are not backed up.	
		Song Repeat	x	x	x			
		User Songs	○	○	x			
	Setting	Arrangement	Accompaniment Score Pattern	x	x	○	Song	Available only when selecting an Audio Song.
			Backing	x	x	○	Song	Available only when selecting an Audio Song.
			Melody Suppressor	x	x	○	Song	Available only when selecting an Audio Song.
			Style	x	x	○	Style	Available only when selecting an Audio Song.
			Part On/Off	x	x	○	Style	Available only when selecting an Audio Song.
		Playback	Stream Lights On/Off	○	○	x		
			Stream Lights Speed	○	○	x		
			Guide Type	○	○	x		Available only when selecting a MIDI Song.
			Quick Start On/Off	○	○	x		Available only when selecting a MIDI Song.
			MIDI Part Channel - Auto Set On/Off	x	x	○	Song	Available only when selecting a MIDI Song.
			MIDI Part Channel - Right	x	x	○	Song	Available only when selecting a MIDI Song.
			MIDI Part Channel - Left	x	x	○	Song	Available only when selecting a MIDI Song.
		Score	Size	○	○	x		
			Part	x	x	○	Song	
			Quantize	x	x	○	Song	Available only when selecting a MIDI Song.
		Chord	Lyric On/Off	○	○	x		Available only when selecting a MIDI Song.
		Lyric	Chord On/Off	○	○	x		Available only when selecting a MIDI Song.
			Language	○	○	x		Available only when selecting a MIDI Song.
		Mixer	Part On/Off	x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.
			Pan	x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.
			Reverb Type	x	x	○	Common	
			Reverb Depth	x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.
			Volume	x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.
		Recording	Recording Method	x	x	○	Song	
			Rec Part On/Off	x	x	x		Available only for MIDI Recording
Rec Channel			x	x	x		Available only for MIDI Recording	
Registration Memory		Registration Memory	○	○	x			
Metronome	Tempo	x	x	○	Others			
	Beat	x	x	x				
	Bell On/Off	○	○	x				
	Volume	○	○	x				
Balance	Style Volume	x	x	○	Style			
	Main Voice Volume	x	x	○	Voice			
	Layer Voice Volume	x	x	○	Voice			
	Left Voice Volume	x	x	○	Voice			
	MIDI Song Volume	x	x	○	Song			
	Audio Song Volume	x	x	○*	Song	*Available only when connected to a Wi-Fi network.		
	Mic Volume	x	x	○	Others			
	Aux In Volume	○	○	○	Others			

Screen		Parameter	Backup *1	Backup/Restore File *2	Registration Memory		Comment	
					Regist	Group		
Utility	Transpose	Keyboard/Style Transpose	x	x	○	Others		
		MIDI Song Transpose	x	x	○	Song		
		Audio Song Transpose	x	x	○	Song		
	Tuning	Master Tune	○	○	x			
		Scale Tune Type	x	x	○	Others		
		Scale Tune Base Note	x	x	○	Others		
	Keyboard	Touch Curve	○	○	x			
		Fixed Velocity	○	○	x			
	Pedal	Main	Right Pedal Function	x	x	○	Others	
			Center Pedal Function	x	x	○	Others	
			Left Pedal Function	x	x	○	Others	
			AUX Pedal Function	x	x	○	Others	
			AUX Pedal Polarity	○	○	x		
		Setting	Part On/Off	x	x	○	Others	
			Half Pedal Point	○	○	x		
			Soft Pedal Depth	x	x	○	Others	
			Glide Up/Down	x	x	○	Others	
Glide Range			x	x	○	Others		
Utility	Pedal	Setting	Glide On Speed	x	x	○	Others	
			Pitch Bend Up/Down	x	x	○	Others	
			Pitch Bend Range	x	x	○	Others	
	Mic	Mic On/Off	x	x	○	Others		
		Mic Volume	x	x	○	Others		
		Mic Setting	x	x	○	Others		
		Mic Reverb Depth	x	x	○	Others		
		Mic Noise Gate On/Off	x	x	○	Others		
		Vocal Harmony Type	x	x	○	Others		
		Vocal Harmony On/Off	x	x	○	Others		
		Vocal Effect On/Off	x	x	○	Others		
		Lead Vocal Volume	x	x	○	Others		
		Harmony Volume	x	x	○	Others		
	Master EQ	Main	Frequency	x	x	○	Others	
			Gain	x	x	○	Others	
			Q	x	x	○	Others	
		Master EQ Select	User Settings	○	○	x		
Sound Setting		Speaker	○	○	x			
	Binaural On/Off	○	○	x				
	IAC On/Off	○	○	x				
	IAC Depth	○	○	x				
	AUX In Noise Gate On/Off	○	○	x				
System	Language	○	x	x				
	Audio Rec Format	○	○	x				
	Auto Power Off	○	○	x				
Instrument		Wi-Fi Setting	x	x	x			

\*1 These parameters are saved even after the application is closed.

\*2 These parameters can be backed up/restored on the Utility Menu.

# MIDI Implementation Chart / MIDI-Implementierungstabelle / Tableau d'implémentation MIDI / Gráfico de implementación MIDI

Yamaha [ Digital Piano ]  
Model P-S500 MIDI Implementation Chart

Date: 4-Feb-2020  
Version: 1.0

Function...	Transmitted	Recognized	Remarks
Basic Channel Default Changed	1 - 16 1 - 16	1 - 16 1 - 16	
Mode Default Messages Altered	3 × *****	3 × ×	
Note Number : True voice	0 - 127 *****	0 - 127 0 - 127	
Velocity Note ON Note OFF	○ 9nH,v=1-127 ○ 8nH,v=1-127	○ 9nH,v=1-127 ○ 9nH,v=0 or 8nH	
After Touch Key's Ch's	× ×	○ ○	
Pitch Bend	○	○ 0 - 24 semi	
Control Change	0,32 ○ 1,5,7,10,11 ○ 16 × 6,38 ○ 64,65,66,67 ○ 71,72,73,74 ○ 80 ○ 81 × 84 ○ 91,93,94 ○ 96,97 × 98,99 ○ 100,101 ○	○ ○ ○ ○ ○ ○ ○ × ○ ○ ○ ○ ○ ○	Bank Select General Purpose Controller Data Entry Sound Controller Portamento Cntrl Effect Depth RPN Inc,Dec NRPN LSB,MSB RPN LSB,MSB
Prog Change : True #	○ 0 - 127 *****	○ 0 - 127	
System Exclusive	○	○	
Common : Song Pos. : Song Sel. : Tune	× × ×	× × ×	
System Real Time: Clock Commands	○ ○	○ ○	
Aux Mes- sages: : All Sound Off : Reset All Cntrls : Local ON/OFF : All Notes OFF : Active Sense : Reset	× × × × ○ ×	○ (120,126,127) ○ (121) ○ (122) ○ (123 - 125) ○ ×	
Notes:			

Mode 1 : OMNI ON , POLY  
Mode 3 : OMNI OFF, POLY

Mode 2 : OMNI ON , MONO  
Mode 4 : OMNI OFF, MONO

○ : Yes 31  
× : No

